

Electrically Isolated

EZO™ Carrier Board Gen 2

Data input

UART or I²C

Voltage input

3.0V – 5.0V

Probe connector

Female SMA


Current consumption

5V **28 mA**


3.3V **22 mA**

Power saving mode
(OFF pin)


2.6mA



Carrier board dimensions




The Electrically Isolated EZO™ Carrier Board works with almost all EZO™ circuits, except the EZO™ Embedded Flow Meter Totalizer.




The Electrically Isolated EZO™ Carrier Board does not come with EZO™ class devices.

Current consumption



i = 28mA



$$+ = 28 + XmA$$

$$i = XmA$$


The current consumption for the Electrically Isolated EZO™ Carrier Board is linear. The table below shows how much current will be consumed when an EZO™ circuit is connected to the Electrically Isolated EZO™ Carrier Board.

	5V	3.3V
No Load	28mA	22mA
EZO™ pH	44mA	35mA
EZO™ ORP	44mA	35mA
EZO™ Dissolved oxygen	44mA	35mA
EZO™ Conductivity (no probe)	55mA	43mA
EZO™ RTD Temperature	44mA	35mA

Pin out

Setting the OFF pin low will shut off the Carrier Board, along with the connected EZO™ circuit. Current consumption will drop to **2.6mA**.


If the **OFF** pin is not used, leave it unconnected or pull to VCC.



Data isolation

This schematic shows exactly how we isolate power and data using the RFM-0505s, SI8600, and a few passive components. The RFM-0505s Isolates the power up to 200mA, 5 volts input = 5 volts output, 3 Volts input = 3 volts output, The SI8600 has two bidirectional data channels, making it ideal for UART and I2C communication. Each channel has a $10\text{k}\Omega$ pull up resistor on both the isolated and non-isolated lines.

Isolated ground is different from non-isolated ground, these two lines should not be connected together.




EZO-ORP™

Embedded ORP Circuit

ISO 11271 Compliant

(determination of redox potential)

Reads	ORP
Range	-1019.9mV – 1019.9mV
Accuracy	+/- 1mV
Response time	1 reading per sec
Supported probes	Any type & brand
Calibration	Single point
Temp compensation	N/A
Data protocol	UART & I ² C
Default I ² C address	98 (0x62)
Operating voltage	3.3V – 5V
Data format	ASCII



PATENT PROTECTED




STOP

SOLDERING THIS DEVICE VOIDS YOUR WARRANTY.

This is sensitive electronic equipment. Get this device working in a solderless breadboard first. Once this device has been soldered it is no longer covered by our warranty.

This device has been designed to be soldered and can be soldered at any time. Once that decision has been made, Atlas Scientific no longer assumes responsibility for the device's continued operation. The embedded systems engineer is now the responsible party.

Get this device working in a solderless breadboard first!



Do not embed this device without testing it in a solderless breadboard!




Table of contents

Circuit dimensions	4	Power and data isolation	7
Power consumption	4	Correct wiring	9
Absolute max ratings	4	Calibration theory	12
Operating principle	5	Default state	14
		Available data protocols	15


UART

UART mode	17
Receiving data from device	18
Sending commands to device	19
LED color definition	20
UART quick command page	21
LED control	22
Find	23
Continuous reading mode	24
Single reading mode	25
Calibration	26
Export calibration	27
Import calibration	28
Naming device	29
Device information	30
Response codes	31
Reading device status	32
Sleep mode/low power	33
Change baud rate	34
Protocol lock	35
Factory reset	36
Change to I ² C mode	37
Manual switching to I ² C	38

I²C

I ² C mode	40
Sending commands	41
Requesting data	42
Response codes	43
LED color definition	44
I²C quick command page	45
LED control	46
Find	47
Taking reading	48
Calibration	49
Export calibration	50
Import calibration	51
Naming device	52
Device information	53
Reading device status	54
Sleep mode/low power	55
Protocol lock	56
I ² C address change	57
Factory reset	58
Change to UART mode	59
Manual switching to UART	60
Circuit footprint	61
Datasheet change log	62
Warranty	65

EZO™ circuit dimensions



Power consumption

Absolute max ratings


	LED	MAX	STANDBY	SLEEP
5V	ON	18.3 mA	16 mA	1.16 mA
	OFF	13.8 mA	13.8 mA	
3.3V	ON	14.5 mA	13.9 mA	0.995 mA
	OFF	13.3 mA	13.3 mA	

Parameter	MIN	TYP	MAX
Storage temperature (EZO™ ORP)	-65 °C		125 °C
Operational temperature (EZO™ ORP)	-40 °C	25 °C	85 °C
VCC	3.3V	5V	5.5V

Operating principle

ORP stands for **oxidation/reduction potential**. Oxidation is the loss of electrons and reduction is the gain of electrons. The output of the probe is represented in millivolts and can be positive or negative.

Just like a pH probe measures hydrogen ion activity in a liquid; an ORP probe measures electron activity in a liquid. The ORP readings represents how strongly electrons are transferred to or from substances in a liquid. Keeping in mind that the readings do not indicate the amount of electrons available for transfer.




When reading the ORP of a liquid that has very few electrons available for transfer ORP readings can appear to be inconsistent.

The water is unreactive and has only trace amounts of electron movement. These readings are equivalent to the readings you see with an unconnected multimeter.

-234.6


Reading A



24.2


Reading B

An ORP probe has a platinum tip that is connected to a silver wire, surrounded by silver chloride. That silver wire is then connected to a KCL reference solution. Because platinum is an unreactive metal it can “silently observe” the electron activity of the liquid without becoming apart of whatever reaction is occurring in the liquid.



606.9

Reading A



605.3

Reading B

Add just a drop of bleach
(which is an oxidizing agent)

Power and data isolation

The Atlas Scientific EZO™ ORP circuit is a very sensitive device. This sensitivity is what gives the ORP circuit its accuracy. This also means that the ORP circuit is capable of reading micro-voltages that are bleeding into the water from unnatural sources such as pumps, solenoid valves or other probes/sensors.


When electrical noise is interfering with the ORP readings it is common to see rapidly fluctuating readings or readings that are consistently off. To verify that electrical noise is causing inaccurate readings, place the ORP probe in a cup of water by itself. The readings should stabilize quickly, confirming that electrical noise was the issue.



When reading ORP and Conductivity or Dissolved Oxygen together, it is **strongly recommended** that the EZO™ ORP circuit is electrically isolated from the EZO™ Conductivity or Dissolved Oxygen circuit.

Basic EZO™

Inline Voltage Isolator




Without isolation, Conductivity and Dissolved Oxygen readings will effect ORP accuracy.

This schematic shows exactly how we isolate data and power using the and a few passive components. The ADM3260 can output isolated power up to 150 mW and incorporates two bidirectional data channels.

This technology works by using tiny transformers to induce the voltage across an air gap. PCB layout requires special attention for EMI/EMC and RF Control, having proper ground planes and keeping the capacitors as close to the chip as possible are crucial for proper performance. The two data channels have a $4.7\text{k}\Omega$ pull up resistor on both the isolated and non-isolated lines (R1, R2, R3, and R4) The output voltage is set using a voltage divider (R5, R6, and R7) this produces a voltage of 3.9V regardless of your input voltage.



Isolated ground is different from non-isolated ground, these two lines should not be connected together.

VCC = 3.0v – 5.5v




✓ Correct wiring


Bread board



Carrier board USB carrier board



Electrically Isolated
EZO™ Carrier Board




✗ Incorrect wiring


Extended leads




Sloppy setup



Perfboards or Protoboards





*Embedded into your device




NEVER
use Perfboards or Protoboards
Flux residue and shorting wires make it very hard to get accurate readings.

*Only after you are familiar with EZO™ circuits operation

**NEVER EXTEND THE CABLE
WITH CHEAP JUMPER WIRES!**



**DO NOT CUT THE PROBE CABLE
WITHOUT REFERING TO *THIS DOCUMENT!***



**ONLY USE SHIELDED CABLES.
REFER TO [THIS DOCUMENT!](#)**

Calibration theory

Simple calibration


UART mode

Continuous readings

Advanced calibration

I²C mode

Continuously request readings



The most important part of calibration is watching the readings during the calibration process.

It's easiest to calibrate the device in its default state (UART mode, with continuous readings enabled).

Switching the device to I²C mode after calibration **will not** affect the stored calibration. If the device must be calibrated in I²C mode be sure to **continuously request readings** so you can see the output from the probe.




The Atlas Scientific EZO™ ORP circuit has a flexible calibration protocol, allowing single point calibration to ***any off the shelf calibration solution.***

However, If this is your first time calibrating the EZO™ ORP circuit, Atlas Scientific recommends using the 225mv calibration solution.



Single point calibration

Remove the soaker bottle and rinse off the ORP probe. Remove the top of the **ORP 225mV** calibration solution pouch. Insert the ORP probe directly into the pouch, and let the probe sit in the calibration solution until the readings stabilize (*small movement from one reading to the next is normal*).



Calibration should be done at least once per year

If the ORP that's being read is continuously on the extremes of the scale (~ -900mV or +900mV) calibration may have to be done more often. The exact frequency of calibration will have to be determined by your engineering team.

Default state UART mode

Baud

9,600

Readings

continuous

Speed


1 reading per second

LED


on




1,000 ms



Green
Standby



Cyan
Taking reading



Transmitting

 Available data protocols

UART

Default

I²C

 Unavailable data protocols

SPI

Analog

RS-485

Mod Bus

4–20mA

UART mode

Settings that are retained if power is cut

Baud rate
Calibration
Continuous mode
Device name
Enable/disable response codes
Hardware switch to I²C mode
LED control
Protocol lock
Software switch to I²C mode

Settings that are **NOT** retained if power is cut

Find
Sleep mode

UART mode

8 data bits no parity
1 stop bit no flow control

Baud 300
1,200
2,400
9,600 default
19,200
38,400
57,600
115,200

RX Data in




TX Data out



Vcc 3.3V – 5.5V

0V  0V




Data format

Reading ORP
Units mV
Encoding ASCII
Format string
Terminator carriage return

Data type floating point
Decimal places 1
Smallest string 2 characters
Largest string 40 characters

Receiving data from device

2 parts



Advanced



ASCII: 2 0 9 . 6 <cr>

Hex: 32 30 39 2E 36 0D

Dec: 50 48 57 46 54 13

Sending commands to device

2 parts




Advanced

ASCII: S I e e p <cr>


Hex: 53 6C 65 65 70 0D

Dec: 83 108 101 101 112 13


LED color definition




Green
UART standby




Cyan
Taking reading



Purple
Changing baud rate



Red
Command not understood



White
Find

5V LED ON
+2.2 mA

3.3V **+0.6 mA**

UART mode

command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	Default state
Baud	change baud rate	pg. 34 9,600
C	enable/disable continuous reading	pg. 24 enabled
Cal	performs calibration	pg. 26 n/a
Export	export calibration	pg. 27 n/a
Factory	enable factory reset	pg. 36 n/a
Find	finds device with blinking white LED	pg. 23 n/a
i	device information	pg. 30 n/a
I2C	change to I ² C mode	pg. 37 not set
Import	import calibration	pg. 28 n/a
L	enable/disable LED	pg. 22 enabled
Name	set/show name of device	pg. 29 not set
Plock	enable/disable protocol lock	pg. 35 disabled
R	returns a single reading	pg. 25 n/a
Sleep	enter sleep mode/low power	pg. 33 n/a
Status	retrieve status information	pg. 32 n/a
*OK	enable/disable response codes	pg. 31 enable

LED control

Command syntax

L,1 <cr> LED on **default**

L,0 <cr> LED off

L,? <cr> LED state on/off?

Example

L,1 <cr>

*OK <cr>

L,0 <cr>


*OK <cr>

L,? <cr>


?L,1 <cr> or ?L,0 <cr>

*OK <cr>

L,1



L,0



Find

Command syntax


This command will disable continuous mode
Send any character or command to terminate find.

Find <cr> LED rapidly blinks white, used to help find device

Example Response

Find <cr>

*OK <cr>



Continuous reading mode

Command syntax

- C,1 <cr> enable continuous readings once per second **default**
- C,n <cr> continuous readings every n seconds (n = 2 to 99 sec)
- C,0 <cr> disable continuous readings
- C,? <cr> continuous reading mode on/off?

Example Response

C,1 <cr>

*OK <cr>
ORP (1 sec) <cr>
ORP (2 sec) <cr>
ORP (n sec) <cr>

C,30 <cr>

*OK <cr>
ORP (30 sec) <cr>
ORP (60 sec) <cr>
ORP (90 sec) <cr>

C,0 <cr>

*OK <cr>

C,? <cr>

?C,1 <cr> or ?C,0 <cr> or ?C,30 <cr>
*OK <cr>

Single reading mode

Command syntax


R <cr> takes single reading

Example Response


R <cr>

209.6 <cr>


*OK <cr>



Green
Standby



Cyan
Taking reading



Transmitting



Calibration

Command syntax

The EZO™ ORP circuit can be calibrated to any known ORP value

- Cal,n <cr>** calibrates the ORP circuit to a set value
- Cal,clear <cr>** delete calibration data
- Cal,? <cr>** device calibrated?

Example

Cal,225 <cr>

Response

***OK <cr>**


Cal,clear <cr>

***OK <cr>**

Cal,? <cr>

?Cal,0 <cr> or ?Cal,1 <cr>

***OK <cr>**



Export calibration

Command syntax

Export: Use this command to download calibration settings

Export,? <cr> calibration string info

Export <cr> export calibration string from calibrated device

Example

Export,? <cr>

Response

10,120 <cr>

Response breakdown

10, 120

of strings to export

of bytes to export

Export strings can be up to 12 characters long, and is always followed by <cr>

Export <cr>

59 6F 75 20 61 72 <cr> (1 of 10)

Export <cr>

65 20 61 20 63 6F <cr> (2 of 10)

(7 more)

⋮

Export <cr>




6F 6C 20 67 75 79 <cr> (10 of 10)

Export <cr>

*DONE

Disabling *OK simplifies this process

Export <cr>



*DONE

Import calibration

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n <cr> import calibration string to new device

Example

Import, 59 6F 75 20 61 72 <cr> (1 of 10)

Import, 65 20 61 20 63 6F <cr> (2 of 10)

⋮

Import, 6F 6C 20 67 75 79 <cr> (10 of 10)

Response


*OK <cr>

*OK <cr>

⋮


*OK <cr>

Import,n <cr>



*OK <cr>

system will reboot



*ER <cr>

* If one of the imported strings is not correctly entered, the device will not accept the import, respond with *ER and reboot.

Naming device

Command syntax

Do not use spaces in the name

Name,n <cr> set name

n = 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Name, <cr> clears name

Up to 16 ASCII characters

Name,? <cr> show name

Example

Response

Name, <cr>

*OK <cr> name has been cleared

Name,zzt <cr>


*OK <cr>

Name,? <cr>


?Name,zzt <cr>

*OK <cr>

Name,zzt



Name,?



*OK <cr>

?Name,zzt <cr>

*OK <cr>

Device information

Command syntax

i <cr> device information

Example Response

i <cr>

?i,ORP,1.97 <cr>
*OK <cr>

Response breakdown

?i, ORP, 1.97
↑ ↑
Device Firmware

Response codes

Command syntax

*OK,1 <cr> enable response **default**
*OK,0 <cr> disable response
*OK,? <cr> response on/off?

Example

R <cr>

209.6 <cr>

***OK <cr>**

***OK,0 <cr>**

no response, *OK disabled

R <cr>

209.6 <cr> *OK disabled

***OK,? <cr>**

?*OK,1 <cr> or ?*OK,0 <cr>

Response

Other response codes

*ER unknown command
*OV over volt (VCC>=5.5V)
*UV under volt (VCC<=3.1V)
*RS reset
*RE boot up complete, ready
*SL entering sleep mode
*WA wake up

**These response codes
cannot be disabled**

Reading device status

Command syntax

Status <cr> voltage at Vcc pin and reason for last restart

Example Response

Status <cr>

?Status,P,5.038 <cr>

*OK <cr>

Response breakdown

?Status, P, 5.038
↑ ↑
Reason for restart Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Sleep mode/low power

Command syntax

Send any character or command to awaken device.

Sleep <cr> enter sleep mode/low power

Example

Sleep <cr>


Response

***OK <cr>**
***SL <cr>**

Any command

***WA <cr>** wakes up device


	STANDBY	SLEEP
5V	16 mA	1.16 mA
3.3V	13.9 mA	0.995 mA



Standby
16 mA



Sleep <cr>



Sleep
1.16 mA

Change baud rate

Command syntax

Baud,n <cr> change baud rate

Example

Baud,38400 <cr>

Response


*OK <cr>

Baud,? <cr>

?Baud,38400 <cr>

*OK <cr>


n = [300
1200
2400
9600 default
19200
38400
57600
115200]



Standby



Baud,38400 <cr>




Changing
baud rate

*OK <cr>



(reboot)



Standby

Protocol lock

Command syntax

Locks device to UART mode.

Plock,1 <cr> enable Plock

Plock,0 <cr> disable Plock **default**

Plock,? <cr> Plock on/off?

Example

Plock,1 <cr>

*OK <cr>

Plock,0 <cr>


*OK <cr>

Plock,? <cr>

?Plock,1 <cr> or ?Plock,0 <cr>


Response

Plock,1



*OK <cr>


I2C,100



cannot change to I²C

*ER <cr>

Short



cannot change to I²C

Factory reset

Command syntax

Clears calibration
LED on
"*OK" enabled



Factory <cr> enable factory reset

Example Response


Factory <cr>

*OK <cr>

Factory <cr>



(reboot)



*OK <cr>

*RS <cr>

*RE <cr>

Baud rate will not change

Change to I²C mode

Command syntax

Default I²C address 98 (0x62)

I²C,n <cr> sets I²C address and reboots into I²C mode

n = any number 1 – 127

Example Response

I²C,100 <cr>

*OK (reboot in I²C mode)




Wrong example

I²C,139 <cr> n > 127

Response

*ER <cr>

I²C,100



Green
*OK <cr>


Blue
now in I²C mode

Manual switching to I²C


- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to PGND
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Green to Blue
- Disconnect ground (power off)
- Reconnect all data and power

Manually switching to I²C will set the I²C address to 98 (0x62)

Example



Wrong Example



I²C mode

The I²C protocol is **considerably more complex** than the UART (RS-232) protocol. Atlas Scientific assumes the embedded systems engineer understands this protocol.

To set your EZO™ device into I²C mode [click here](#)

Settings that are retained if power is cut

Calibration
Change I²C address
Hardware switch to UART mode
LED control
Protocol lock
Software switch to UART mode

Settings that are **NOT** retained if power is cut



Find
Sleep mode

I²C mode

I²C address (0x01 – 0x7F)
98 (0x62) default

V_{cc} 3.3V – 5.5V

Clock speed 100 – 400 kHz



Data format

Reading ORP
Units mV
Encoding ASCII
Format string

Data type floating point
Decimal places 1
Smallest string 2 characters
Largest string 40 characters


Sending commands to device

5 parts




Example



Start 98 (0x62) Write Sleep Stop
I²C address Command




Advanced



Requesting data from device



Advanced




1 50 48 57 46 54 0 = 209.6
Dec Dec
ASCII

Response codes

After a command has been issued, a 1 byte response code can be read in order to confirm that the command was processed successfully.

Reading back the response code is completely optional, and is not required for normal operation.



Example

```
I2C_start;  
I2C_address;  
I2C_write(EZO_command);  
I2C_stop;
```

```
delay(300);
```



Processing delay

```
I2C_start;  
I2C_address;  
Char[ ] = I2C_read;  
I2C_stop;
```


If there is no processing delay or the processing delay is too short, the response code will always be 254.

Response codes


Single byte, not string

- | | |
|-----|-----------------------------|
| 255 | no data to send |
| 254 | still processing, not ready |
| 2 | syntax error |
| 1 | successful request |

LED color definition




I²C standby




Green


Taking reading



Changing I²C address



Command not understood



White

Find

5V	LED ON +2.2 mA
3.3V	+0.6 mA

I²C mode

command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	
Baud	switch back to UART mode	pg. 59
Cal	performs calibration	pg. 49
Export	export calibration	pg. 50
Factory	enable factory reset	pg. 58
Find	finds device with blinking white LED	pg. 47
i	device information	pg. 53
I2C	change I ² C address	pg. 57
Import	import calibration	pg. 51
L	enable/disable LED	pg. 46
Name	set/show name of device	pg. 52
Plock	enable/disable protocol lock	pg. 56
R	returns a single reading	pg. 48
Sleep	enter sleep mode/low power	pg. 55
Status	retrieve status information	pg. 54

LED control

Command syntax

300ms  processing delay

L,1 LED on **default**

L,0 LED off

L,? LED state on/off?

Example

L,1


Wait 300ms

1
Dec
0
Null

L,0


Wait 300ms

1
Dec
0
Null


L,?


Wait 300ms


1
Dec
?L,1
ASCII
0
Null

or

1
Dec
?L,0
ASCII
0
Null



L,1



L,0

Find

300ms  processing delay

Command syntax


This command will disable continuous mode
Send any character or command to terminate find.

Find LED rapidly blinks white, used to help find device

Example Response

Find

 Wait 300ms
1 Dec **0** Null



Taking reading

Command syntax

900ms  processing delay


R return 1 reading

Example

Response


R

 Wait 900ms
1 Dec 209.6 ASCII 0 Null




Green

Taking reading



Transmitting



Blue

Standby

Calibration

Command syntax

900ms  processing delay

Cal,n calibrates the ORP circuit to a set value

Cal,clear delete calibration data

Cal,? device calibrated?

The EZO™ ORP circuit can be calibrated to any known ORP value

Example

Response

Cal,225


 Wait 900ms
1 Dec 0 Null

Cal,clear

 Wait 300ms
1 Dec 0 Null

Cal,?

 Wait 300ms
1 Dec ?Cal,0 0 or 1 Dec ?Cal,1 0 ASCII Null Null



Export calibration

300ms  processing delay

Command syntax

Export: Use this command to download calibration settings

Export,? calibration string info

Export export calibration string from calibrated device

Example

(optional)

Export,?

Response



Wait 300ms

1 Dec 10,120 ASCII 0 Null

Response breakdown

10, 120

↑ ↑

of strings to export

of bytes to export

Export strings can be up to 12 characters long

Export



Wait 300ms

1 Dec 59 6F 75 20 61 72 0 Null

(1 of 10)

Export



Wait 300ms

1 Dec 65 20 61 20 63 6F 0 Null

(2 of 10)

(7 more)

⋮

Export



Wait 300ms

1 Dec 6F 6C 20 67 75 79 0 Null

(10 of 10)

Export



Wait 300ms

1 Dec *DONE 0 Null

Import calibration

300ms  processing delay

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n import calibration string to new device

Example

Import, 59 6F 75 20 61 72 (1 of 10)

Import, 65 20 61 20 63 6F (2 of 10)

⋮

Import, 6F 6C 20 67 75 79 (10 of 10)


Response

 1 0 Null
Wait 300ms


 1 0 Null
Wait 300ms

⋮
 1 0 Null
Wait 300ms

Import,n



system will reboot



* If one of the imported strings is not correctly entered, the device will not accept the import and reboot.

Naming device

300ms  processing delay

Command syntax

Do not use spaces in the name

Name,n set name

n =

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Name, clears name

Up to 16 ASCII characters

Name,? show name

Example

Response

Name,



1 Dec 0 Null

name has been cleared

Name,zzt




1 Dec 0 Null

Name,?




1 Dec ?Name,zzt 0 Null

Name,zzt



Name,?



1 0

1 ?Name,zzt 0

Device information

Command syntax

300ms  processing delay

i device information

Example Response

i



Wait 300ms

1
Dec

?i,ORP, 19.7
ASCII

0
Null

Response breakdown

?i, ORP, 1.97

↑
Device

↑
Firmware

Reading device status

Command syntax

300ms  processing delay

Status voltage at Vcc pin and reason for last restart

Example Response

Status



Wait 300ms

1

?Status,P,5.038

Dec

ASCII

0

Null

Response breakdown

?Status, P,
Reason for restart 5.038
 Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Sleep mode/low power

Command syntax

Sleep enter sleep mode/low power

Send any character or command to awaken device.

Example

Response

Sleep

no response


Do not read status byte after issuing sleep command.

Any command


wakes up device

	STANDBY	SLEEP
5V	16 mA	1.16 mA


3.3V	13.9 mA	0.995 mA
-------------	----------------	-----------------



Standby



Sleep



Sleep

Protocol lock

Command syntax

300ms  processing delay

Plock,1 enable Plock

Locks device to I²C mode.

Plock,0 disable Plock

default

Plock,? Plock on/off?

Example

Plock,1

 Wait 300ms

1
Dec
0
Null

Plock,0


 Wait 300ms

1
Dec
0
Null


Plock,?

 Wait 300ms


1
Dec
?Plock,1
ASCII
0
Null



Baud, 9600



cannot change to UART



cannot change to UART

I²C address change

Command syntax

300ms  processing delay

I²C,n sets I²C address and reboots into I²C mode

Example Response

I²C,100

device reboot

(no response given)



Warning!

Changing the I²C address will prevent communication between the circuit and the CPU until the CPU is updated with the new I²C address.


Default I²C address is 98 (0x62).

n = any number 1 – 127

I²C,100



(reboot)



Factory reset

Command syntax

Factory reset will not take the device out of I²C mode.

Factory enable factory reset

I²C address will not change

Example Response




Factory

device reboot

(no response given)

Clears calibration
LED on
Response codes enabled

Factory



Change to UART mode

Command syntax

Baud,n switch from I²C to UART


Example Response

Baud,9600



reboot in UART mode

(no response given)


n = [300
1200
2400
9600
19200
38400
57600
115200]



Baud,9600



(reboot)




Changing to
UART mode


Manual switching to UART

- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to PGND
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Blue to Green
- Disconnect ground (power off)
- Reconnect all data and power



Example



Wrong Example




EZO™ circuit footprint




2.54mm
(0.1")


1 In your CAD software place a 8 position header.



2 Place a 3 position header at both top and bottom of the 8 position.



3 Delete the 8 position header. The two 3 position headers are now 17.78mm (0.7") apart from each other.



Datasheet change log

Datasheet V 5.0

Revised naming device info on pages 29 & 52.

Datasheet V 4.9

Revised single point calibration information and art on pg 13.

Datasheet V 4.8

Moved Default state to pg 14.

Datasheet V 4.7

Updated firmware to V2.11 on pg 63.

Datasheet V 4.6

Revised response for the sleep command in UART mode on pg 33.

Datasheet V 4.5

Revised calibration theory on page 12, and added more information on the Export calibration and Import calibration commands.

Datasheet V 4.4

Revised isolation schematic on pg. 10

Datasheet V 4.3

Changed "Max rate" to "Response time" on cover page.

Datasheet V 4.2

Removed note from certain commands about firmware version.

Datasheet V 4.1

Added information to calibration theory on pg 8.

Datasheet V 4.0

Revised definition of response codes on pg 42.

Datasheet V 3.9

Revised isolation information on pg 9.

Datasheet V 3.8

Revised Plock pages to show default value.

Datasheet V 3.7

Added new commands:

"Find" pages 23 (UART) & 46 (I²C).

"Export/Import calibration" pages 27 (UART) & 49 (I²C).

Added new feature to continuous mode "C,n" pg 24.

Datasheet V 3.6

Revised circuit illustrations throughout datasheet.

Datasheet V 3.5

Added accuracy range on cover page, and revised isolation info on pg 10.

Datasheet V 3.4

Revised entire datasheet.

Firmware updates

V1.5 – Baud rate change (Nov 6, 2014)

- Change default baud rate to 9600

V1.6 – I²C bug (Dec 1, 2014)

- Fixed I²C bug where the circuit may inappropriately respond when other I²C devices are connected.

V1.7 – Factory (April 14, 2015)

- Changed "X" command to "Factory"

V1.95 – Plock (March 31, 2016)

- Added protocol lock feature "Plock"

V1.96 – EEPROM (April 26, 2016)

- Fixed bug where EEPROM would get erased if the circuit lost power 900ms into startup

V1.97 – EEPROM (Oct 10, 2016)

- Fixed bug in the cal clear command, improves how it calculates the ORP
- Added calibration saving and loading

V2.10 – (May 9, 2017)

- Added "Find" command.
- Added "Export/import" command.
- Modified continuous mode to be able to send readings every "n" seconds.

V2.11 – (July 17, 2017)

- Fixed bug where calibration would restore itself after restart, despite being cleared.

V2.12 – (Oct 18, 2021)

- Internal update for new part compatibility.

V2.13 – (Nov 12, 2021)

- Fixed bug in I²C mode with timing and sleep mode.

Warranty

Atlas Scientific™ Warranties the EZO™ class ORP circuit to be free of defect during the debugging phase of device implementation, or 30 days after receiving the EZO™ class ORP circuit (which ever comes first).

The debugging phase

The debugging phase as defined by Atlas Scientific™ is the time period when the EZO™ class ORP circuit is inserted into a bread board, or shield. If the EZO™ class ORP circuit is being debugged in a bread board, the bread board must be devoid of other components. If the EZO™ class ORP circuit is being connected to a microcontroller, the microcontroller must be running code that has been designed to drive the EZO™ class ORP circuit exclusively and output the EZO™ class ORP circuit data as a serial string.

It is important for the embedded systems engineer to keep in mind that the following activities will void the EZO™ class ORP circuit warranty:

- **Soldering any part of the EZO™ class ORP circuit.**
- **Running any code, that does not exclusively drive the EZO™ class ORP circuit and output its data in a serial string.**
- **Embedding the EZO™ class ORP circuit into a custom made device.**
- **Removing any potting compound.**

Reasoning behind this warranty

Because Atlas Scientific™ does not sell consumer electronics; once the device has been embedded into a custom made system, Atlas Scientific™ cannot possibly warranty the EZO™ class ORP circuit, against the thousands of possible variables that may cause the EZO™ class ORP circuit to no longer function properly.

Please keep this in mind:


- 1. All Atlas Scientific™ devices have been designed to be embedded into a custom made system by you, the embedded systems engineer.**
- 2. All Atlas Scientific™ devices have been designed to run indefinitely without failure in the field.**
- 3. All Atlas Scientific™ devices can be soldered into place, however you do so at your own risk.**

Atlas Scientific™ is simply stating that once the device is being used in your application, Atlas Scientific™ can no longer take responsibility for the EZO™ class ORP circuits continued operation. This is because that would be equivalent to Atlas Scientific™ taking responsibility over the correct operation of your entire device.

EZO-pH™


Embedded pH Circuit
ISO 10523 Compliant
 (determination of pH)

Reads	pH
Range	.001 – 14.000
Resolution	.001
Accuracy	+/- 0.002
pH reading time	800ms
Supported probes	Any type & brand
Calibration	1, 2, 3 point
Temp compensation	Yes
Data protocol	UART & I²C
Default I ² C address	99 (0x63)
Operating voltage	3.3V – 5V
Data format	ASCII






PATENT PROTECTED

The EZO™ pH Circuit has all the features of this bench top meter.



Isolated Power Supply

=



- 1 Three decimal pH reading
- 2 Temperature used for reading
- 3 Calibration slope
- 4 Extended range capability
- 5 Immediate reading
- 6 Timed readings
- 7 Set device name
- 8 Voltage usage
- 9 Multi point calibration
- 10 Manual temperature compensation

The EZO™ pH Circuit is compatible with any brand of pH probe.

 Available data protocols

UART

Default

I²C

 Unavailable data protocols

SPI

Analog

RS-485

Mod Bus

4–20mA

STOP


SOLDERING THIS DEVICE VOIDS YOUR WARRANTY.

Are there specific soldering instructions? Yes, see page 71.

Can you make a warranty claim after soldering? No.

If you have not used this product before; Observe how a properly working sensor behaves **BEFORE** embedding it into your PCB.

Get this device working using one of these methods first.



Do not embed before you have experience with this sensor.




Table of contents

Available data protocols	3	Correct wiring	9
Circuit dimensions	6	Default state	12
Power consumption	6	Circuit footprint	73
Absolute max ratings	6	Datasheet change log	74
Electrical isolation	7	Warranty	78
Calibration theory	63		
Understanding pH Slope	68		


UART

UART mode	13
LED color definition	14
Receiving data from device	15
Sending commands to device	16
UART quick command page	17
LED control	18
Find	19
Continuous reading mode	20
Single reading mode	21
Calibration	22
Export calibration	23
Import calibration	24
Slope	25
Extended pH scale	26
Temperature compensation	27
Naming device	28
Device information	29
Response codes	30
Reading device status	31
Sleep mode/low power	32
Change baud rate	33
Protocol lock	34
Factory reset	35
Change to I ² C mode	36
Manual switching to I ² C	37

I²C

I ² C mode	39
Sending commands	40
Requesting data	41
Response codes	42
LED color definition	43
I ² C quick command page	44
LED control	45
Find	46
Taking reading	47
Calibration	48
Export calibration	49
Import calibration	50
Slope	51
Extended pH scale	52
Temperature compensation	53
Naming device	54
Device information	55
Reading device status	56
Sleep mode/low power	57
Protocol lock	58
I ² C address change	59
Factory reset	60
Change to UART mode	61
Manual switching to UART	62

EZO™ circuit dimensions



Power consumption

	LED	MAX	STANDBY	SLEEP
5V	ON	18.3 mA	16 mA	1.16 mA
	OFF	13.8 mA	13.8 mA	
3.3V	ON	14.5 mA	13.9 mA	0.995 mA
	OFF	13.3 mA	13.3 mA	

Absolute max ratings

Parameter	MIN	TYP	MAX
Storage temperature (EZO™ pH)	-65 °C		125 °C
Operational temperature (EZO™ pH)	-40 °C	25 °C	85 °C
VCC	3.3V	5V	5.5V

Electrical isolation

The Atlas Scientific EZO™ pH circuit is a very sensitive device. This sensitivity is what gives the pH circuit its accuracy. It also means that the pH circuit can read micro-voltages bleeding into the water from unnatural sources such as pumps, solenoid valves, or other probes/sensors.


When electrical noise interferes with the pH readings, it is common to see rapidly fluctuating readings or readings that are pinned to 14 or 0. To verify that electrical noise is causing inaccurate readings, place the pH probe in a cup of water by itself. The readings should stabilize quickly, confirming that electrical noise was the issue.



Advice:

1. When reading pH along with other sensors, electrical isolation is strongly recommended.
2. Never build a commercial product without electrical isolation.

Atlas Scientific offers several different electrical isolation products that can be used in your design. Select the electrical isolation product that works best for your design.




For various reasons, you may need to build your own electrical isolator. Because electrical isolation is so important, we have published our isolation schematic for anyone to use.

This isolation schematic is based on the ADM3260, which can output up to 150 mW of isolated power. PCB layout requires special attention for EMI/EMC and RF Control. Having good ground planes and keeping the capacitors as close to the chip as possible are crucial for proper performance.

The two data channels have a $4.7\text{k}\Omega$ pull-up resistor on both the isolated and non-isolated lines (R1, R2, R3, and R4). The output voltage is set using a voltage divider (R5, R6, and R7). This produces a voltage of 3.9V regardless of your input voltage.

Isolated ground is different from non-isolated ground, these two lines should not be connected together.


VCC = 3.0v – 5.5v




Non-isolated

Isolated


✓ Correct wiring




Bread board




Bread board via USB



Non-Isolated
EZO™ Carrier Board



Electrically Isolated
EZO™ Carrier Board




USB
carrier board

✗ Incorrect wiring


Extended leads




Sloppy setup



Perfboards or Protoboards



*Embedded into your device





NEVER
use Perfboards or Protoboards


Flux residue and shorting wires make
it very hard to get accurate readings.

*Only after you are familiar
with EZO™ circuits operation

**NEVER EXTEND THE CABLE
WITH CHEAP JUMPER WIRES!**



**DO NOT CUT THE PROBE CABLE
WITHOUT REFERING TO *THIS DOCUMENT!***




Default state UART mode


Baud	9,600
Readings	continuous
Units	pH
Speed	1 reading per second
LED	on




1,000 ms




Green
Standby



Cyan
Taking reading



Transmitting



Solid Blue LED
in I²C mode
Not UART ready

UART mode

8 data bits no parity
1 stop bit no flow control

Baud 300
1,200
2,400
9,600 default
19,200
38,400
57,600
115,200

RX Data in




TX Data out



Vcc 3.3V – 5.5V

0V VCC 0V




Data format


Reading pH
Encoding ASCII
Format string
Terminator carriage return

Data type floating point
Decimal places 3
Smallest string 4 characters
Largest string 40 characters


LED color definition




Green
UART standby




Cyan
Taking reading




Purple
Changing
baud rate



Red
Command
not understood



White
Find



Blue
I2C standby

5V	LED ON +2.2 mA
3.3V	+0.6 mA

Settings that are retained if power is cut


Baud rate
Calibration
Continuous mode
Device name
Enable/disable response codes
Hardware switch to I²C mode
LED control
Protocol lock
Software switch to I²C mode

Settings that are **NOT** retained if power is cut

Find
Sleep mode
Temperature compensation

Receiving data from device

2 parts



Advanced



ASCII: 9 . 5 6 0 <cr>

Hex: 39 2E 35 36 30 0D

Dec: 57 46 53 54 48 13

Sending commands to device

2 parts



Advanced

ASCII:

S	I	e	e	p	<cr>
---	---	---	---	---	------

Hex:

53	6C	65	65	70	0D
----	----	----	----	----	----

Dec:

83	108	101	101	112	13
----	-----	-----	-----	-----	----

UART mode

command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	Default state
Baud	change baud rate	pg. 33 9,600
C	enable/disable continuous reading	pg. 20 enabled
Cal	performs calibration	pg. 22 n/a
Export	export calibration	pg. 23 n/a
Factory	enable factory reset	pg. 35 n/a
Find	finds device with blinking white LED	pg. 19 n/a
i	device information	pg. 29 n/a
I2C	change to I ² C mode	pg. 36 not set
Import	import calibration	pg. 24 n/a
L	enable/disable LED	pg. 18 enabled
Name	set/show name of device	pg. 28 not set
pHext	enable/disable extended pH scale	pg. 26 disabled
Plock	enable/disable protocol lock	pg. 34 disabled
R	returns a single reading	pg. 21 n/a
Sleep	enter sleep mode/low power	pg. 32 n/a
Slope	returns the slope of the pH probe	pg. 25 n/a
Status	retrieve status information	pg. 31 enable
T	temperature compensation	pg. 27 25°C
*OK	enable/disable response codes	pg. 30 enable

LED control

Command syntax

L,1 <cr> LED on **default**

L,0 <cr> LED off

L,? <cr> LED state on/off?

Example Response

L,1 <cr>


*OK <cr>

L,0 <cr>


*OK <cr>

L,? <cr>

?L,1 <cr> or ?L,0 <cr>
*OK <cr>



L,1



L,0

Find

Command syntax


This command will disable continuous mode
Send any character or command to terminate find.

Find <cr> LED rapidly blinks white, used to help find device

Example Response

Find <cr>

*OK <cr>



Continuous reading mode

Command syntax

- C,1 <cr> enable continuous readings once per second **default**
- C,n <cr> continuous readings every n seconds (n = 2 to 99 sec)
- C,0 <cr> disable continuous readings
- C,? <cr> continuous reading mode on/off?

Example Response

C,1 <cr>	*OK <cr> pH (1 sec) <cr> pH (2 sec) <cr> pH (n sec) <cr>
C,30 <cr>	*OK <cr> pH (30 sec) <cr> pH (60 sec) <cr> pH (90 sec) <cr>
C,0 <cr>	*OK <cr>
C,? <cr>	?C,1 <cr> or ?C,0 <cr> or ?C,30 <cr> *OK <cr>

Single reading mode

Command syntax

A single reading takes 800ms


R <cr> takes single reading

Example Response


R <cr>

9.560 <cr>


*OK <cr>



Green
Standby



Cyan
Taking reading



Transmitting



800 ms

Calibration

Command syntax

Issuing the cal,mid command after the EZO™ pH circuit has been calibrated, will clear the other calibration points. Full calibration will have to be redone.

Cal,mid,n	<cr> single point calibration at midpoint
Cal,low,n	<cr> two point calibration at lowpoint
Cal,high,n	<cr> three point calibration at highpoint
Cal,clear	<cr> delete calibration data
Cal,?	<cr> device calibrated?

Example Response

Cal,mid,7.00 <cr>	*OK <cr>
Cal,low,4.00 <cr>	*OK <cr>
Cal,high,10.00 <cr>	*OK <cr>
Cal,clear <cr>	*OK <cr>
Cal,? <cr>	?Cal,0 <cr> or ?Cal,1 <cr> or one point ?Cal,2 <cr> or ?Cal,3 <cr> two point three point *OK <cr>

Export calibration

Command syntax

Export: Use this command to download calibration settings

Export,? <cr> calibration string info

Export <cr> export calibration string from calibrated device

Example

Export,? <cr>

Response

10,120 <cr>

Response breakdown

10, 120

of strings to export

of bytes to export

Export strings can be up to 12 characters long,
and is always followed by <cr>

Export <cr>

59 6F 75 20 61 72 <cr> (1 of 10)

Export <cr>

65 20 61 20 63 6F <cr> (2 of 10)

(7 more)

⋮

Export <cr>




6F 6C 20 67 75 79 <cr> (10 of 10)

Export <cr>

*DONE

Disabling *OK simplifies this process

Export <cr>



Import calibration

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n <cr> import calibration string to new device

Example

Import, 59 6F 75 20 61 72 <cr> (1 of 10)

Import, 65 20 61 20 63 6F <cr> (2 of 10)

⋮

Import, 6F 6C 20 67 75 79 <cr> (10 of 10)

Response




*OK <cr>

*OK <cr>

⋮


*OK <cr>

Import,n <cr>



*OK <cr>

system will reboot



* If one of the imported strings is not correctly entered, the device will not accept the import, respond with *ER and reboot.

Slope

Command syntax

After calibrating a pH probe issuing the slope command will show how closely (in percentage) the calibrated pH probe is working compared to the "ideal" pH probe.

Slope,? <cr> returns the slope of the pH probe

Example Response

Slope,? <cr>

**?Slope,99.7,100.3,-0.89 <cr>
*OK <cr>**

Response breakdown

?Slope,

99.7


↑
99.7% is how closely the slope of the **acid** calibration line matched the "ideal" pH probe.

100.3

↑
100.3% is how closely the slope of the **base** calibration matches the "ideal" pH probe.

-0.89

↑
This is how many millivolts the zero point is off from true 0.



Extended pH scale

Very strong acids and bases can exceed the traditional pH scale. This command extends the pH scale to show below 0 and above 14.

Command syntax

Lowest possible reading: -1.6

Highest possible reading: 15.6

- pHext,0 <cr>** extended pH scale off (0–14) **default**
- pHext,1 <cr>** extended pH scale on (-1.6–15.6)
- pHext,? <cr>** extended pH scale on/off?

Example

pHext,1 <cr>

Response

*OK <cr>

pHext,0 <cr>

pHext,? <cr>

*OK <cr>

?pHext,1 <cr> or ?pHext,0 <cr>



pH = 0.000



pH = -1.220

Temperature compensation

Command syntax

Default temperature = 25°C
Temperature is always in Celsius
Temperature is not retained if power is cut

T,n <cr> n = any value; floating point or int

T,? <cr> compensated temperature value?

RT,n <cr> set temperature compensation and take a reading

Example

T,19.5 <cr>

Response

*OK <cr>

RT,19.5 <cr>


*OK <cr>

8.91 <cr>

T,? <cr>

?T,19.5 <cr>

*OK <cr>



Naming device

Command syntax

Do not use spaces in the name

Name,n <cr> set name

n = 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Name, <cr> clears name

Up to 16 ASCII characters

Name,? <cr> show name

Example

Response

Name, <cr>

*OK <cr> name has been cleared

Name,zzt <cr>


*OK <cr>

Name,? <cr>


?Name,zzt <cr>

*OK <cr>

Name,zzt



Name,?



*OK <cr>

?Name,zzt <cr>

*OK <cr>

Device information

Command syntax

i <cr> device information

Example Response

i <cr>

?i,pH,2.16 <cr>

*OK <cr>

Response breakdown

?i, pH, 2.16
↑ ↑
Device Firmware

Response codes

Command syntax

*OK,1 <cr> enable response **default**
*OK,0 <cr> disable response
*OK,? <cr> response on/off?

Example

R <cr>

*OK,0 <cr>

R <cr>

*OK,? <cr>

Response

9.560 <cr>
***OK <cr>**

no response, *OK disabled

9.560 <cr> *OK disabled

?*OK,1 <cr> or ?*OK,0 <cr>

Other response codes

*ER unknown command
*OV over volt (VCC>=5.5V)
*UV under volt (VCC<=3.1V)
*RS reset
*RE boot up complete, ready
*SL entering sleep mode
*WA wake up

**These response codes
cannot be disabled**

Reading device status

Command syntax

Status <cr> voltage at Vcc pin and reason for last restart

Example Response

Status <cr>

?Status,P,5.038 <cr>

*OK <cr>

Response breakdown

?Status, P,

Reason for restart

5.038

↑

Voltage at Vcc

Restart codes

P powered off

S software reset

B brown out

W watchdog

U unknown

Sleep mode/low power

Command syntax

Send any character or command to awaken device.

Sleep <cr> enter sleep mode/low power

Example


Sleep <cr>

***OK <cr>**
***SL <cr>**


Any command

***WA <cr>** wakes up device

	STANDBY	SLEEP
5V	16 mA	1.16 mA
3.3V	13.9 mA	0.995 mA



Sleep <cr>



Change baud rate

Command syntax

Baud,n <cr> change baud rate

Example

Baud,38400 <cr>

Response


*OK <cr>

Baud,? <cr>

?Baud,38400 <cr>

*OK <cr>


n = [300
1200
2400
9600 default
19200
38400
57600
115200]



Standby



Baud,38400 <cr>




Changing
baud rate

*OK <cr>



(reboot)



Standby

Protocol lock

Command syntax

Locks device to UART mode.

Plock,1 <cr> enable Plock

Plock,0 <cr> disable Plock **default**

Plock,? <cr> Plock on/off?

Example

Plock,1 <cr>

*OK <cr>


Plock,0 <cr>

*OK <cr>

Plock,? <cr>


?Plock,1 <cr> or ?Plock,0 <cr>

Response



*OK <cr>


I²C,100



cannot change to I²C

*ER <cr>

Short



cannot change to I²C

Factory reset

Command syntax

Clears calibration
LED on
"*OK" enabled


Factory <cr> enable factory reset

Example Response


Factory <cr>

*OK <cr>

Factory <cr>



(reboot)



*OK <cr>

*RS <cr>

*RE <cr>

Baud rate will not change

Change to I²C mode

Command syntax

Default I²C address 99 (0x63)

I²C,n <cr> sets I²C address and reboots into I²C mode

n = any number 1 – 127

Example Response

I²C,100 <cr>

*OK (reboot in I²C mode)



Wrong example

I²C,139 <cr> n > 127


Response

*ER <cr>

I²C,100



(reboot)



Green

*OK <cr>

Blue


now in I²C mode

Manual switching to I²C


- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to PGND
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Green to Blue
- Disconnect ground (power off)
- Reconnect all data and power

Manually switching to I²C will set the I²C address to 99 (0x63)

Example



Wrong Example



I²C mode

The I²C protocol is **considerably more complex** than the UART (RS-232) protocol. Atlas Scientific assumes the embedded systems engineer understands this protocol.

To set your EZO™ device into I²C mode [click here](#)

Settings that are retained if power is cut

Calibration
Change I²C address
Hardware switch to UART mode
LED control
Protocol lock
Software switch to UART mode

Settings that are **NOT** retained if power is cut



Find
Sleep mode
Temperature compensation

I²C mode

I²C address (0x01 – 0x7F)
99 (0x63) default

V_{CC} **3.3V – 5.5V**

Clock speed 100 – 400 kHz




Data format

Reading	pH	Data type	floating point
Units	pH	Decimal places	3
Encoding	ASCII	Smallest string	4 characters
Format	string	Largest string	40 characters

Sending commands to device


5 parts




Example

Start 99 (0x63) Write Sleep Stop



I²C address Command




Advanced



Requesting data from device



Advanced



1 57 46 53 54 48 0 = 9.560


Dec Dec

ASCII

Response codes

After a command has been issued, a 1 byte response code can be read in order to confirm that the command was processed successfully.

Reading back the response code is completely optional, and is not required for normal operation.



Example

```
I2C_start;  
I2C_address;  
I2C_write(EZO_command);  
I2C_stop;
```

```
delay(300); →  Processing delay
```

```
I2C_start;  
I2C_address;  
Char[ ] = I2C_read;  
I2C_stop;
```


If there is no processing delay or the processing delay is too short, the response code will always be 254.

Response codes

Single byte, not string


255	no data to send
254	still processing, not ready
2	syntax error
1	successful request

LED color definition




Blue

I²C standby




Green

Taking reading




Purple

Changing I²C address



Red


Command not understood



White

Find

5V	LED ON +2.2 mA
3.3V	+0.6 mA



Solid Green LED

in UART mode
Not I²C ready

I²C mode

command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	
Baud	switch back to UART mode	pg. 61
Cal	performs calibration	pg. 48
Export	export calibration	pg. 49
Factory	enable factory reset	pg. 60
Find	finds device with blinking white LED	pg. 46
i	device information	pg. 55
I2C	change I ² C address	pg. 59
Import	import calibration	pg. 50
L	enable/disable LED	pg. 45
Name	set/show name of device	pg. 54
pHext	enable/disable extended pH scale	pg. 52
Plock	enable/disable protocol lock	pg. 58
R	returns a single reading	pg. 47
Sleep	enter sleep mode/low power	pg. 57
Slope	returns the slope of the pH probe	pg. 51
Status	retrieve status information	pg. 56
T	temperature compensation	pg. 53

LED control

Command syntax

300ms  processing delay

L,1 LED on **default**

L,0 LED off

L,? LED state on/off?

Example

L,1


 Wait 300ms
1 Dec 0 Null

L,0


 Wait 300ms
1 Dec 0 Null

L,?

 Wait 300ms
1 Dec ?L,1 ASCII 0 or 1 Dec ?L,0 ASCII 0 Null



L,1



L,0

Find

300ms  processing delay

Command syntax





This command will disable continuous mode
Send any character or command to terminate find.

Find LED rapidly blinks white, used to help find device

Example Response

Find

 Wait 300ms
1 Dec **0** Null



Taking reading

Command syntax

900ms  processing delay

R return 1 reading

Example

Response


R



1
Dec


9.560
ASCII

0
Null




Green

Taking reading



Transmitting



Blue

Standby

Calibration

Command syntax

900ms  processing delay

Issuing the cal,mid command after the EZO™ pH circuit has been calibrated, will clear the other calibration points. Full calibration will have to be redone.

Cal,mid,n	single point calibration at midpoint
Cal,low,n	two point calibration at lowpoint
Cal,high,n	three point calibration at highpoint
Cal,clear	delete calibration data
Cal,?	device calibrated?

Example

Response

Cal,mid,7.00

 Wait 900ms
1 Dec 0 Null

Cal,low,4.00

 Wait 900ms
1 Dec 0 Null

Cal,high,10.00

 Wait 900ms
1 Dec 0 Null

Cal,clear

 Wait 300ms
1 Dec 0 Null

Cal,?

 Wait 300ms
1 Dec ?Cal,0 0 Null or 1 Dec ?Cal,1 0 Null
or 1 Dec ?Cal,2 0 Null ASCII two point or 1 Dec ?Cal,3 0 Null ASCII three point

Export calibration

300ms  processing delay

Command syntax

Export: Use this command to download calibration settings

Export,? calibration string info

Export export calibration string from calibrated device

Example

Response

Export,?



1 10,120 0
Dec ASCII Null

Response breakdown

10, 120
↑ ↑
of strings to export # of bytes to export

Export strings can be up to 12 characters long

Export



1 59 6F 75 20 61 72 0
Dec ASCII Null

(1 of 10)

Export



1 65 20 61 20 63 6F 0
Dec ASCII Null

(2 of 10)

(7 more)

⋮

Export



1 6F 6C 20 67 75 79 0
Dec ASCII Null

(10 of 10)

Export



1 *DONE 0
Dec ASCII Null

Import calibration

300ms  processing delay

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n import calibration string to new device

Example

Import, 59 6F 75 20 61 72 (1 of 10)

Import, 65 20 61 20 63 6F (2 of 10)

⋮

Import, 6F 6C 20 67 75 79 (10 of 10)


Response

 1 0 Null
Wait 300ms


 1 0 Null
Wait 300ms

⋮
 1 0 Null
Wait 300ms

Import,n



system will reboot



* If one of the imported strings is not correctly entered, the device will not accept the import and reboot.

Slope

Command syntax

300ms  processing delay

After calibrating a pH probe issuing the slope command will show how closely (in percentage) the calibrated pH probe is working compared to the "ideal" pH probe.

Slope,? returns the slope of the pH probe

Example Response

Slope,?



Wait 300ms

1

?Slope,99.7,100.3,-0.89

0

Dec

ASCII

Null

Response breakdown

?Slope,

99.7



99.7% is how closely the slope of the **acid** calibration line matched the "ideal" pH probe.

100.3




100.3% is how closely the slope of the **base** calibration line matches the "ideal" pH probe.

-0.89



This is how many millivolts the zero point is off from true 0.



Extended pH scale

300ms  processing delay

Very strong acids and bases can exceed the traditional pH scale. This command extends the pH scale to show below 0 and above 14.

Command syntax

Lowest possible reading: -1.6
Highest possible reading: 15.6

pHext,0	extended pH scale off (0–14)	default
pHext,1	extended pH scale on (-1.6–15.6)	
pHext,?	extended pH scale on/off?	

Example

Response

pHext,1

 Wait 300ms 1 Dec 0 Null

pHext,0

 Wait 300ms 1 Dec 0 Null

pHext,?

 Wait 300ms 1 Dec ?pHext,1 ASCII 0 Null or 1 Dec ?pHext,0 ASCII 0 Null



pH = 0.000



pH = -1.220

Temperature compensation

Command syntax

Default temperature = 25°C
Temperature is always in Celsius
Temperature is not retained if power is cut

- T,n n = any value; floating point or int 300ms  processing delay
- T,? compensated temperature value?
- RT,n set temperature compensation and take a reading

Example

T,19.5



Wait 300ms

1
Dec

0
Null

RT,19.5



Wait 900ms

1
Dec

8.91
ASCII

0
Null

T,?




Wait 300ms


1
Dec

?T,19.5
ASCII

0
Null



T,19.5



Naming device

300ms  processing delay

Command syntax

Do not use spaces in the name

Name,n set name

n =

— 1 — 2 — 3 — 4 — 5 — 6 — 7 — 8 — 9 — 10 — 11 — 12 — 13 — 14 — 15 — 16

Name, clears name

Up to 16 ASCII characters

Name,? show name

Example

Response

Name,



1 Dec 0 Null

name has been cleared

Name,zzt




1 Dec 0 Null

Name,?




1 Dec ?Name,zzt 0 Null

Name,zzt



Name,?



1 0

1 ?Name,zzt 0

Device information

Command syntax

300ms  processing delay

i device information

Example Response

i



Wait 300ms

1
Dec

?i,pH,1.98
ASCII

0
Null

Response breakdown

?i, pH, 1.98
↑ ↑
Device Firmware

Reading device status

Command syntax

300ms  processing delay

Status voltage at Vcc pin and reason for last restart

Example Response

Status



Wait 300ms

1

?Status,P,5.038

Dec

ASCII

0

Null

Response breakdown

?Status, P, 5.038

Reason for restart

Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Sleep mode/low power

Command syntax

Sleep enter sleep mode/low power

Send any character or command to awaken device.

Example Response

Sleep


no response

Do not read status byte after issuing sleep command.


Any command

wakes up device


	STANDBY	SLEEP
5V	16 mA	1.16 mA
3.3V	13.9 mA	0.995 mA



Standby



Sleep



Sleep

Protocol lock

Command syntax

300ms  processing delay

Plock,1 enable Plock

Locks device to I²C mode.

Plock,0 disable Plock **default**

Plock,? Plock on/off?

Example

Plock,1

 Wait 300ms
1 Dec 0 Null

Plock,0



 Wait 300ms
1 Dec 0 Null

Plock,?


 Wait 300ms
1 Dec ?Plock,1 ASCII 0 Null

Plock,1

Baud, 9600



cannot change to UART



cannot change to UART

I²C address change

Command syntax

300ms  processing delay

I²C,n sets I²C address and reboots into I²C mode

Example Response

I²C,100

device reboot

(no response given)



Warning!

Changing the I²C address will prevent communication between the circuit and the CPU until the CPU is updated with the new I²C address.


Default I²C address is 99 (0x63).

n = any number 1 – 127

I²C,100



(reboot)



Factory reset

Command syntax

Factory reset will not take the device out of I²C mode.

Factory enable factory reset

I²C address will not change

Example Response



Factory

device reboot


(no response given)

Clears calibration
LED on
Response codes enabled

Factory



(reboot)



Change to UART mode

Command syntax

Baud,n switch from I²C to UART



Example Response

Baud,9600


reboot in UART mode

(no response given)


$$n = \begin{cases} 300 \\ 1200 \\ 2400 \\ 9600 \\ 19200 \\ 38400 \\ 57600 \\ 115200 \end{cases}$$



Baud,9600



(reboot)




Changing to UART
mode


Manual switching to UART

- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to PGND
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Blue to Green
- Disconnect ground (power off)
- Reconnect all data and power

Example



Wrong Example




Calibration theory

The accuracy of your readings is directly related to the quality of your calibration.
(Calibration is not difficult, and a little bit of care goes a long way).

Single, Two point, or Three point calibration accuracy

Single point calibration




Two point calibration



Three point calibration



Confirm the pH probe is working correctly



A new Atlas Scientific pH probe, still in its soaker bottle will read a pH of **~3.8 – 4.2**

If your pH probe gives a reading of **zero, seven** or **14** continuously and that reading cannot be changed no matter what solution the probe is in, your probe cannot be calibrated and may be damaged.

Contact Atlas Scientific customer support for assistance.

Calibration order

If this is your first time calibrating the EZO™ pH circuit, we recommend that you follow this calibration order.



1 Mid point

2 Low point

3 High point

Calibration solutions

The Atlas Scientific EZO™ pH circuit can work with any brand or value of calibration solution. **We recommend using calibration solutions that have simple values.**




✓ Simple value

✗ Complex value

While you can use calibration solutions that have complex values, we recommend avoiding unnecessary complexity. **Unusually specific calibration values should be treated with suspicion.**

Best practices for calibration

Always watch the readings throughout the calibration process.
Issue calibration commands once the readings have stabilized.



⚠ Never do a blind calibration! ⚠

Issuing a calibration command before the readings stabilize will result in drifting readings.



Best practices for calibration

Avoid extended stabilization time.






Letting the probes pre-calibration readings stabilize over an extended period will cause your calibrated readings to take a long time to stabilize.

Avoid frequent recalibrations.

if it ain't broke, don't fix it.



pH probes lose accuracy slowly. Frequent recalibrations to insure high accuracy will often have the opposite effect. It is far more likely that you will misscalibrate the probe rather than improve its accuracy.

1. Mid point calibration





✓ Mid point calibrated

2. Low point calibration



✓ Low point calibrated

3. High point calibration



✓ High point calibrated

Optional steps:

Confirm your calibration accuracy using the slope command.
Recalibre a single point if required.

Understanding pH slope

The slope function is a powerful tool used to verify calibration and determine the overall health of a pH probe. By evaluating the slope of a pH probe's response curve, you can determine how well a pH probe was calibrated or when that probe is reaching end of life.

Slope and calibration are directly related. The slope is updated when a calibration command is given. The slope does not update automatically.

Generally speaking, all pH probes behave the same way. This means a probe's response to calibration can be compared to a simulated pH probe that is mathematically perfect in all ways.



The slope is broken into three sections; acid, base, and neutral.
Each section is evaluated separately.

Acid (pH 1–6.9)

Base (pH 7.1–14)

Neutral (pH 7)

An uncalibrated pH probe will have a mathematically perfect slope. Because no pH probe is mathematically perfect, the slope can be used to determine if the pH was calibrated.


Uncalibrated slope: 100, 100, 0 (acid, base, neutral)

% % mV

The first two numbers are percentages, and the third is millivolts. The slope shows that the probe's response to acid and base is 100% correct, and it detects 0 mv in a pH 7. Because such perfection does not exist in the real world, we know this probe was not calibrated.

Understanding pH slope

pH 7 is the absence of pH; it is not an acid or a base. Therefore it should always be your first calibration point. It is equivalent to the tare function on a scale because it establishes the probe's zero point.



cal,mid,7
***OK**

After pH 7 calibration, use the slope command to see how the probe performed during calibration.

The slope after pH 7 calibration: 100, 100, -1.2

Here we see the probe reads -1.2mV in pH 7. The closer this number is to 0, the better. A new pH probe should give a millivolt offset no greater than -5mV to 5mV. Over time this number's distance to 0 may increase; the larger the number, the lower the accuracy. A reading >10mV will result in noticeable performance issues.

It is important to remember that a high number is not definitive evidence that the probe is inaccurate or malfunctioning. It is very common to see a high number if the calibration solution was contaminated and not actually its stated value.

Understanding pH slope

The next two calibration points ($\text{pH } 4$ and $\text{pH } 10$) report their slope in percentage. A new pH probe should have a slope of $>95\%$.


The slope after pH 4 calibration: 98.2, 100, -1.2

The slope after pH 10 calibration: 98.2, 97.8, -1.2

Tips:

Throughout this explanation, we have looked at the slope after each calibration event. This is unnecessary; in reality, it is best to fully calibrate the probe and look at the slope once calibration has been completed.


To gain a deeper understanding of how slope affects the stability and accuracy of a pH probe, intentionally miscalibrate the probe and see how it affects the slope.



Soldering


Do not directly solder an EZO circuit to your PCB. If something goes wrong during the soldering process it may become impossible to correct the problem. It is simply not worth the risk.

Instead, solder female header pins to your PCB and place the EZO device in the female headers.



**Avoid using rosin core solder.
Use as little flux as possible.**

Flux residue will severely affect your readings. Any Flux residue that comes in contact with the PRB pins or your probes connector will cause a "flux short".




You **MUST** remove all the flux residue from your PCB after soldering.

Soldering

Removing flux residue can be done with commercially available products such as flux off or you can use alcohol and a tooth brush.



Remove EZO Circuit and soak in alcohol for 10 mins.




Bush with tooth brush.



Soak in alcohol for 5 mins.





Let it dry in the air.



What does a flux short look like?


- 1: Readings move slowly and take serval minutes to reach the correct value.
- 2: Readings are pinned to 0, 7 or 14.

EZO™ circuit footprint




**2.54mm
(0.1")**


1 In your CAD software place a 8 position header.



2 Place a 3 position header at both top and bottom of the 8 position.



3 Delete the 8 position header. The two 3 position headers are now 17.78mm (0.7") apart from each other.



Datasheet change log

Datasheet V 6.1

Revised electrical isolation section on page 7.

Datasheet V 6.0

Revised entire document.

Datasheet V 5.9

Revised naming device info on pages 32 & 58.

Datasheet V 5.8

Revised calibration info and art on pages 11 & 12.

Datasheet V 5.7

Added new command:

"Extended pH Scale" pages 30 (UART) & 56 (I²C).

Datasheet V 5.6

Revised information on the slope command found on pages 29 & 54.

Datasheet V 5.5

Revised artwork within datasheet.

Datasheet V 5.4

Moved the Default state to pg 14.

Datasheet V 5.3

Revised response for the sleep command in UART mode on pg 35.

Datasheet V 5.2

Revised calibration theory on page 11, and added more information on the Export calibration and Import calibration commands.

Datasheet V 5.1

Revised isolation schematic on pg 10.

Datasheet V 5.0

Added more information about temperature compensation on pages 29 & 53.

Datasheet V 4.9

Changed "Max rate" to "Response time" on cover page.

Datasheet V 4.8

Added new command:

"RT,n" for Temperature compensation located on pages 29 (UART) & 53 (I²C).
Added firmware information to Firmware update list.

Datasheet V 4.7

Removed note from certain commands about firmware version.

Datasheet V 4.6

Added information to calibration theory on pg 7.

Datasheet V 4.5

Revised definition of response codes on pg 44.

Datasheet V 4.4

Added resolution range to cover page.

Datasheet V 4.3

Revised isolation information on pg 9.

Datasheet V 4.2

Revised Plock pages to show default value.

Datasheet V 4.1

Added new commands:

"Find" pages 23 (UART) & 46 (I²C).
"Export/Import calibration" pages 27 (UART) & 49 (I²C).
Added new feature to continuous mode "C,n" pg 24.

Datasheet V 4.0

Added accuracy range on cover page, and revised isolation info on pg. 10.

Datasheet V 3.9

Revised calibration theory on pg. 7.

Datasheet V 3.8

Revised entire datasheet.

Firmware updates

V1.5 – Baud rate change (Nov 6, 2014)

- Change default baud rate to 9600

V1.6 – I²C bug (Dec 1, 2014)

- Fixed I²C bug where the circuit may inappropriately respond when other I²C devices are connected.

V1.7 – Factory (April 14, 2015)

- Changed "X" command to "Factory"

V1.95 – Plock (March 31, 2016)

- Added protocol lock feature "Plock"

V1.96 – EEPROM (April 26, 2016)

- Fixed bug where EEPROM would get erased if the circuit lost power 900ms into startup

V1.97 – EEPROM (Oct 10, 2016)

- Added the option to save and load calibration.

V1.98 – EEPROM (Nov 14, 2016)

- Fixed bug during calibration process.

V2.10 – (May 9, 2017)

- Added "Find" command.
- Added "Export/import" command.
- Modified continuous mode to be able to send readings every "n" seconds.

V2.11 – (June 12, 2017)

- Fixed "I" command to return "pH" instead of "PH".

V2.12 – (April 16, 2018)

- Fixed "cal,clear" was not clearing stored calibration in EEPROM.
- Added "RT" command to Temperature compensation.

V2.13 – (June 25, 2019)

- Added calibration offset to slope.
- Added calibration with temperature compensation.

V2.14 – (June 10, 2020)

- Added extended pH scale.

v2.15 – (Nov 3, 2021)

- Internal update for new part compatibility.

v2.16 – (Nov 19, 2021)

- Fixed bug in I²C mode with timing and sleep mode.

Warranty

Atlas Scientific™ Warranties the EZO™ class pH circuit to be free of defect during the debugging phase of device implementation, or 30 days after receiving the EZO™ class pH circuit (which ever comes first).

The debugging phase

The debugging phase as defined by Atlas Scientific™ is the time period when the EZO™ class pH circuit is inserted into a bread board, or shield. If the EZO™ class pH circuit is being debugged in a bread board, the bread board must be devoid of other components. If the EZO™ class pH circuit is being connected to a microcontroller, the microcontroller must be running code that has been designed to drive the EZO™ class pH circuit exclusively and output the EZO™ class pH circuit data as a serial string.

It is important for the embedded systems engineer to keep in mind that the following activities will void the EZO™ class pH circuit warranty:

- **Soldering any part of the EZO™ class pH circuit.**
- **Running any code, that does not exclusively drive the EZO™ class pH circuit and output its data in a serial string.**
- **Embedding the EZO™ class pH circuit into a custom made device.**
- **Removing any potting compound.**

Reasoning behind this warranty

Because Atlas Scientific™ does not sell consumer electronics; once the device has been embedded into a custom made system, Atlas Scientific™ cannot possibly warranty the EZO™ class pH circuit, against the thousands of possible variables that may cause the EZO™ class pH circuit to no longer function properly.

Please keep this in mind:

- 1. All Atlas Scientific™ devices have been designed to be embedded into a custom made system by you, the embedded systems engineer.**
- 2. All Atlas Scientific™ devices have been designed to run indefinitely without failure in the field.**
- 3. All Atlas Scientific™ devices can be soldered into place, however you do so at your own risk.**

Atlas Scientific™ is simply stating that once the device is being used in your application, Atlas Scientific™ can no longer take responsibility for the EZO™ class pH circuits continued operation. This is because that would be equivalent to Atlas Scientific™ taking responsibility over the correct operation of your entire device.

EZO-EC™

Embedded Conductivity Circuit

ISO 7888 Compliant

(determination of electrical conductivity)

Reads

Conductivity = $\mu\text{S}/\text{cm}$

Total dissolved solids = ppm

Salinity = PSU (ppt) 0.00 – 42.00

Specific gravity

(sea water only) = 1.00 – 1.300

Range

0.07 – 500,000+ $\mu\text{S}/\text{cm}$

Accuracy

+/- 2%

EC reading time

600ms

Supported probes **K 0.01 – K 10.2 any brand**

Calibration

2 or 3 point

Temp compensation

Yes

Data protocol

UART & I²C

Default I²C address


100 (0x64)

Operating voltage

3.3V – 5V


Data format

ASCII



PATENT PROTECTED

The EZO™ EC Circuit has all the features of this bench top meter.



- 1 Multi decimal EC reading
- 2 Temperature used for reading
- 3 Enable EC readings
- 4 Enable TDS/ ppm readings
- 5 Variable TDS conversion factor
- 6 Enable salinity readings
- 7 Enable specific gravity readings

- 8 Immediate reading
- 9 Timed readings
- 10 Set device name
- 11 Voltage usage
- 12 Multi-point variable calibration
- 13 Temperature compensation

The EZO Complete-EC™ is compatible with any brand of EC probe from K 0.01–K10.2

Conductivity probe range

The EZO™ Conductivity circuit is compatible with any brand of two-conductor conductivity probe, ranging from:

K 0.01



K 10.2

Atlas Scientific™ has tested three different K value probe types:

K 0.1



K 1.0



K 10



accurate reading range

0.07µS/cm – 50,000µS/cm

TDS (ppm) 0 – 25,000

Salinity (ppt) 0 – 33

accurate reading range

5µS/cm – 200,000+µS/cm

TDS (ppm) 2 – 100,000

Salinity (ppt) 0 – 42*

**salinity scale cannot go any higher*

accurate reading range

10µS/cm – 1S/cm

TDS (ppm) 5 – 500,000

Salinity (ppt) 0 – 42*

**salinity scale cannot go any higher*

Atlas Scientific™ does not know what the accurate reading range would be for conductivity probes, other than the above mentioned values. Determining the accurate reading range of such probes, i.e. **K 2.6**, or **K 0.66**, is the responsibility of the embedded systems engineer.

Resolution

The EZO™ Conductivity circuit, employs a method of scaling resolution. As the conductivity increases the resolution between readings decreases.

The EZO™ Conductivity circuit will output conductivity readings where the first **4 digits** are valid and the others are set to 0. This excludes conductivity readings that are less than 9.99. In that case, only 3 conductivity digits will be output.

0.07 – 99.99

Resolution = **0.01 μ S/cm**

100.1 – 999.9

Resolution = **0.1 μ S/cm**

1,000 – 9,999


Resolution = **1.0 μ S/cm**

10,000 – 99,990

Resolution = **10 μ S/cm**

100,000 – 999,900

Resolution = **100 μ S/cm**



 Available data protocols

UART

Default

I²C

 Unavailable data protocols

SPI

Analog

RS-485

Mod Bus

4–20mA

STOP

SOLDERING THIS DEVICE VOIDS YOUR WARRANTY.




Are there specific soldering instructions? Yes, see page 73.

Can you make a warranty claim after soldering? No.

If you have not used this product before; Observe how a properly working sensor behaves **BEFORE** embedding it into your PCB.

Get this device working using one of these methods first.



Do not embed before you have experience with this sensor.




Table of contents

Available data protocols	5	Correct wiring	11
Circuit dimensions	8	Default state	12
Power consumption	8	Circuit footprint	75
Absolute max ratings	8	Datasheet change log	76
Electrical isolation	9	Warranty	81
Conductivity probe range	3		
Resolution	4		
Calibration theory	65		


UART

UART mode	13
LED color definition	14
Receiving data from device	15
Sending commands to device	16
UART quick command page	17
LED control	18
Find	19
Continuous reading mode	20
Single reading mode	21
Calibration	22
Change TDS conversion factor	23
Export calibration	24
Import calibration	25
Setting the probe type	26
Temperature compensation	27
Enable/disable parameters	28
Naming device	29
Device information	30
Response codes	31
Reading device status	32
Sleep mode/low power	33
Change baud rate	34
Protocol lock	35
Factory reset	36
Change to I ² C mode	37
Manual switching to I ² C	38

I²C

I ² C mode	40
Sending commands	41
Requesting data	42
Response codes	43
LED color definition	44
I ² C quick command page	45
LED control	46
Find	47
Taking reading	48
Calibration	49
Change TDS conversion factor	50
Export calibration	51
Import calibration	52
Setting the probe type	53
Temperature compensation	54
Enable/disable parameters	55
Naming device	56
Device information	57
Reading device status	58
Sleep mode/low power	59
Protocol lock	60
I ² C address change	61
Factory reset	62
Change to UART mode	63
Manual switching to UART	64

EZO™ circuit dimensions



Power consumption

Absolute max ratings

	LED	MAX	STANDBY	SLEEP
5V	ON	50 mA	18.14 mA	0.7 mA
	OFF	45 mA	15.64 mA	
3.3V	ON	35 mA	16.85 mA	0.4 mA
	OFF	34 mA	15.85 mA	

Parameter	MIN	TYP	MAX
Storage temperature (EZO™ Conductivity)	-60 °C		150 °C
Operational temperature (EZO™ Conductivity)	-40 °C	25 °C	125 °C
VCC	3.3V	5V	5.5V

Electrical isolation

Conductivity readings will introduce significant electrical interference into your water. This electrical interference will affect other sensors, such as pH, ORP, and dissolved oxygen. Electrical isolation is 100% effective in preventing this electrical interference.

Unlike other probes, a conductivity probe provides a low-resistance pathway from your water to your electronics. If an accidental electrical surge passes through your water, it will travel up your conductivity probe and into your electronics. Electrical isolation is 100% effective at stopping an accidental electrical surge from destroying your computer system.




Advice:

When reading conductivity along with other sensors, electrical isolation is strongly recommended.
Never build a commercial product without electrical isolation.


Atlas Scientific offers several different electrical isolation products that can be used in your design. Select the electrical isolation product that works best for your design.



Basic EZO™
Inline Voltage Isolator



Vertical Isolator



Electrically Isolated
EZO™ Carrier Board



Gen 2 Electrically Isolated
USB EZO™ Carrier Board



Whitebox T1



Whitebox T3



Whitebox T3



Electrically Isolated EZO™
Carrier Board (old style)


For various reasons, you may need to build your own electrical isolator. Because electrical isolation is so important, we have published our isolation schematic for anyone to use.

This isolation schematic is based on the ADM3260, which can output up to 150 mW of isolated power. PCB layout requires special attention for EMI/EMC and RF Control. Having good ground planes and keeping the capacitors as close to the chip as possible are crucial for proper performance.


The two data channels have a $4.7\text{k}\Omega$ pull-up resistor on both the isolated and non-isolated lines (R1, R2, R3, and R4). The output voltage is set using a voltage divider (R5, R6, and R7). This produces a voltage of 3.9V regardless of your input voltage.

Isolated ground is different from non-isolated ground, these two lines should not be connected together.


VCC = 3.0v – 5.5v




✓ Correct wiring




Bread board




Bread board via USB



Non-Isolated
EZO™ Carrier Board



Electrically Isolated
EZO™ Carrier Board




USB
carrier board

✗ Incorrect wiring


Extended leads




Sloppy setup



Perfboards or Protoboards



*Embedded into your device




NEVER
use Perfboards or Protoboards
Flux residue and shorting wires make it very hard to get accurate readings.

***Only after you are familiar with EZO™ circuits operation**

Default state UART mode

Baud	9,600
Readings	continuous
Units	$\mu\text{S}/\text{cm}$
Speed	1 reading per second
LED	on



Solid Blue LED
in I²C mode
Not UART ready

UART mode

8 data bits no parity
1 stop bit no flow control


Baud 300
1,200
2,400
9,600 default
19,200
38,400
57,600
115,200

RX Data in

TX Data out

Vcc 3.3V – 5.5V

0V VCC 0V



Data format

Reading

Conductivity = **Default**

Total dissolved solids
Salinity
Specific gravity

Terminator

carriage return

Data type

floating point

Decimal places

3

Smallest string

3 characters

Largest string


40 characters

Order EC,TDS,SAL,SG


Encoding ASCII

Format string


LED color definition




Green
UART standby




Cyan
Taking reading




Purple
Changing
baud rate



Red
Command
not understood



White
Find



Blue
I2C standby

5V	LED ON +2.5 mA
3.3V	+1 mA

Settings that are retained if power is cut


- Baud rate
- Calibration
- Continuous mode
- Device name
- Enable/disable parameters
- Enable/disable response codes
- Hardware switch to I²C mode
- LED control
- Protocol lock
- Software switch to I²C mode

Settings that are **NOT** retained if power is cut

- Find
- Sleep mode
- Temperature compensation

Receiving data from device

2 parts



Advanced


ASCII: 1 , 4 1 3 <cr>

Hex: 31 2C 34 31 33 0D

Dec: 49 44 52 49 51 13

Sending commands to device

2 parts



Advanced

ASCII: S I e e p <cr>

Hex: 53 6C 65 65 70 0D

Dec: 83 108 101 101 112 13

UART mode

command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	Default state
Baud	change baud rate	pg. 34 9,600
C	enable/disable continuous reading	pg. 20 enabled
Cal	performs calibration	pg. 22 n/a
Export	export calibration	pg. 24 n/a
Factory	enable factory reset	pg. 36 n/a
Find	finds device with blinking white LED	pg. 19 n/a
i	device information	pg. 30 n/a
I2C	change to I ² C mode	pg. 37 not set
Import	import calibration	pg. 25 n/a
K	Set probe type	pg. 26 K 1.0
L	enable/disable LED	pg. 18 enabled
Name	set/show name of device	pg. 29 not set
O	enable/disable parameters	pg. 28 all enabled
Plock	enable/disable protocol lock	pg. 35 disabled
R	returns a single reading	pg. 21 n/a
Sleep	enter sleep mode/low power	pg. 33 n/a
Status	retrieve status information	pg. 32 enable
T	temperature compensation	pg. 27 25°C
TDS	change the TDS conversion factor	pg. 23 0.54
*OK	enable/disable response codes	pg. 31 enable

LED control

Command syntax

L,1 <cr> LED on **default**

L,0 <cr> LED off

L,? <cr> LED state on/off?

Example

L,1 <cr>

*OK <cr>

L,0 <cr>


*OK <cr>

L,? <cr>


?L,1 <cr> or ?L,0 <cr>

*OK <cr>

L,1



L,0



Find

Command syntax


This command will disable continuous mode
Send any character or command to terminate find.

Find <cr> LED rapidly blinks white, used to help find device

Example Response

Find <cr>

*OK <cr>



Continuous reading mode

Command syntax

- C,1 <cr> enable continuous readings once per second **default**
- C,n <cr> continuous readings every n seconds (n = 2 to 99 sec)
- C,0 <cr> disable continuous readings
- C,? <cr> continuous reading mode on/off?

Example Response

C,1 <cr>	*OK <cr> EC,TDS,SAL,SG (1 sec) <cr> EC,TDS,SAL,SG (2 sec) <cr> EC,TDS,SAL,SG (3 sec) <cr>
C,30 <cr>	*OK <cr> EC,TDS,SAL,SG (30 sec) <cr> EC,TDS,SAL,SG (60 sec) <cr> EC,TDS,SAL,SG (90 sec) <cr>
C,0 <cr>	*OK <cr>
C,? <cr>	?C,1 <cr> or ?C,0 <cr> or ?C,30 <cr> *OK <cr>

Single reading mode


Command syntax

R <cr> takes single reading


Example Response

R <cr>


1,413 <cr>
*OK <cr>



Green
Standby



Cyan
Taking reading



Transmitting



Calibration

Command syntax

Dry calibration must always be done first!

Cal,dry	<cr>	dry calibration
Cal,n	<cr>	single point calibration, where n = any value
Cal,low,n	<cr>	low end calibration, where n = any value
Cal,high,n	<cr>	high end calibration, where n = any value
Cal,clear	<cr>	delete calibration data
Cal,?	<cr>	device calibrated?

Example

Response

Cal,dry <cr>	*OK <cr>
Cal,84 <cr>	*OK <cr>
Cal,low,12880 <cr>	*OK <cr>
Cal,high,80000 <cr>	*OK <cr>
Cal,clear <cr>	*OK <cr>
Cal,? <cr>	?CAL,0 <cr> or ?CAL,1 <cr> or ?CAL,2 two point three point *OK <cr>

Two point calibration:

Step 1. "cal,dry"

Step 2. "cal,n"

Calibration complete!

Three point calibration:

Step 1 "cal,dry"

Step 2 "cal,low,n"

Step 3 "cal,high.n"

Calibration complete!

Changing the TDS (ppm) conversion factor

Command syntax

There are several different conversion factors used to read TDS(ppm). For some applications, it may be necessary to use a conversion factor other than the default value of 0.54

TDS,n <cr> set custom conversion factor, n = any value between 0.01 – 1.00

TDS,? <cr> conversion factor being used

Example

TDS,? <cr>

Response

?TDS,0.54 <cr>
*OK <cr>

R <cr>

EC TDS
↓ ↓
100,54 <cr>
*OK <cr>

TDS,0.46 <cr>

*OK <cr>

R <cr>

EC TDS
↓ ↓
100,46 <cr>
*OK <cr>

Common conversion factors

NaCl 0.47 – 0.50

KCL 0.50 - 0.57

"442" 0.65 – 0.85

Formula

EC x conversion factor = TDS

Export calibration

Command syntax

Export: Use this command to download calibration settings

Export,? <cr> calibration string info

Export <cr> export calibration string from calibrated device

Example

Export,? <cr>

Response

10,120 <cr>

Response breakdown

10, 120

of strings to export

of bytes to export

Export strings can be up to 12 characters long,
and is always followed by <cr>

Export <cr>

59 6F 75 20 61 72 <cr> (1 of 10)

Export <cr>

65 20 61 20 63 6F <cr> (2 of 10)

(7 more)

⋮

Export <cr>




6F 6C 20 67 75 79 <cr> (10 of 10)

Export <cr>

*DONE

Disabling *OK simplifies this process

Export <cr>



*DONE

Import calibration

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n <cr> import calibration string to new device

Example

Import, 59 6F 75 20 61 72 <cr> (1 of 10)

Import, 65 20 61 20 63 6F <cr> (2 of 10)

⋮

Import, 6F 6C 20 67 75 79 <cr> (10 of 10)

Response


*OK <cr>

*OK <cr>

⋮


*OK <cr>

Import,n <cr>



*OK <cr>

system will reboot



* If one of the imported strings is not correctly entered, the device will not accept the import, respond with *ER and reboot.

Setting the probe type

Command syntax

K 1.0 is the default value

K,n <cr> n = any value; floating point in ASCII

K,? <cr> probe K value?

Example

K,10 <cr>

Response

***OK <cr>**

K,? <cr>

?K,10 <cr>

***OK <cr>**



K 0.1



K 1.0



K 10

Temperature compensation

Command syntax

Default temperature = 25°C
Temperature is always in Celsius
Temperature is not retained if power is cut

T,n <cr> n = any value; floating point or int

T,? <cr> compensated temperature value?

RT,n <cr> set temperature compensation and take a reading

Example

T,19.5 <cr>

Response

*OK <cr>

RT,19.5 <cr>


*OK <cr>

8.91 <cr>

T,? <cr>

?T,19.5 <cr>

*OK <cr>



Enable/disable parameters from output string

Command syntax

O, [parameter],[1,0] <cr> enable or disable output parameter

O,? <cr> enabled parameter?

Example

O,EC,1 / O,EC,0 <cr>

Response

*OK <cr> enable / disable conductivity

O,TDS,1 / O,TDS,0 <cr>

*OK <cr> enable / disable total dissolved solids

O,S,1 / O,S,0 <cr>

*OK <cr> enable / disable salinity

O,SG,1 / O,SG,0 <cr>

*OK <cr> enable / disable specific gravity

O,? <cr>

? ,O,EC,TDS,S,SG <cr> if all are enabled

Parameters

EC Conductivity = $\mu\text{S}/\text{cm}$

TDS Total dissolved solids = ppm

S Salinity = PSU (ppt) 0.00 – 42.00

SG Specific gravity (sea water only) = 1.00 – 1.300

* If you disable all possible data types
your readings will display "no output".

Followed by 1 or 0

1 enabled

0 disabled

Naming device

Command syntax

Do not use spaces in the name

Name,n <cr> set name

n = 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Name, <cr> clears name

Up to 16 ASCII characters

Name,? <cr> show name

Example

Response

Name, <cr>

*OK <cr> name has been cleared

Name,zzt <cr>


*OK <cr>

Name,? <cr>


?Name,zzt <cr>

*OK <cr>

Name,zzt



Name,?



*OK <cr>

?Name,zzt <cr>

*OK <cr>

Device information

Command syntax

i <cr> device information

Example Response

i <cr>

?i,EC,2.16 <cr>
*OK <cr>

Response breakdown

?i, EC, 2.16
 ↑ ↑
 Device Firmware

Response codes

Command syntax

*OK,1 <cr> enable response **default**
*OK,0 <cr> disable response
*OK,? <cr> response on/off?

Example

R <cr>

1,413 <cr>

*OK <cr>

*OK,0 <cr>

no response, *OK disabled

R <cr>

1,413 <cr> *OK disabled

*OK,? <cr>

?*OK,1 <cr> or ?*OK,0 <cr>

Response

Other response codes

*ER unknown command
*OV over volt (VCC>=5.5V)
*UV under volt (VCC<=3.1V)
*RS reset
*RE boot up complete, ready
*SL entering sleep mode
*WA wake up

These response codes
cannot be disabled

Reading device status

Command syntax

Status <cr> voltage at Vcc pin and reason for last restart

Example Response

Status <cr>

?Status,P,5.038 <cr>

*OK <cr>

Response breakdown

?Status, P, 5.038
↑ ↑
Reason for restart Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Sleep mode/low power

Command syntax

Send any character or command to awaken device.

Sleep <cr> enter sleep mode/low power

Example

Sleep <cr>

Response


***OK <cr>**
***SL <cr>**

Any command



***WA <cr>** wakes up device

	STANDBY	SLEEP
5V	18.14 mA	0.7 mA

3.3V	16.85 mA	0.4 mA
-------------	-----------------	---------------



Standby
18.14 mA



Sleep
0.7 mA

Change baud rate

Command syntax

Baud,n <cr> change baud rate

Example

Baud,38400 <cr>

Response


*OK <cr>

Baud,? <cr>


?Baud,38400 <cr>

*OK <cr>

n = [300
1200
2400
9600 default
19200
38400
57600
115200]




Standby



Baud,38400 <cr>

Changing
baud rate

*OK <cr>



Standby

Protocol lock

Command syntax

Locks device to UART mode.

Plock,1 <cr> enable Plock

Plock,0 <cr> disable Plock **default**

Plock,? <cr> Plock on/off?

Example

Plock,1 <cr>

*OK <cr>


Plock,0 <cr>

*OK <cr>

Plock,? <cr>


?Plock,1 <cr> or ?Plock,0 <cr>

Response



*OK <cr>


I2C,100



cannot change to I²C

*ER <cr>

Short



cannot change to I²C

Factory reset

Command syntax

Clears calibration
LED on
"*OK" enabled



Factory <cr> enable factory reset

Example Response


Factory <cr>

*OK <cr>

Factory <cr>



(reboot)



*OK <cr>

*RS <cr>

*RE <cr>

Baud rate will not change

Change to I²C mode

Command syntax

Default I²C address 100 (0x64)

I²C,n <cr> sets I²C address and reboots into I²C mode

n = any number 1 – 127

Example Response

I²C,100 <cr>

*OK (reboot in I²C mode)




Wrong example

I²C,139 <cr> n > 127

Response

*ER <cr>

I²C,100



Green
*OK <cr>


Blue
now in I²C mode

Manual switching to I²C


- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to the right PRB
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Green to Blue
- Disconnect ground (power off)
- Reconnect all data and power

Manually switching to I²C will set the I²C address to 100 (0x64)

Example



Wrong Example



I²C mode

The I²C protocol is **considerably more complex** than the UART (RS-232) protocol. Atlas Scientific assumes the embedded systems engineer understands this protocol.

To set your EZO™ device into I²C mode [click here](#)

Settings that are retained if power is cut

Calibration
Change I²C address
Enable/disable parameters
Hardware switch to UART mode
LED control
Protocol lock
Software switch to UART mode

Settings that are **NOT** retained if power is cut



Find
Sleep mode
Temperature compensation

I²C mode

I²C address (0x01 – 0x7F)
100 (0x64) default

V_{cc} 3.3V – 5.5V

Clock speed 100 – 400 kHz



Data format

Reading

Conductivity = Default

Total dissolved solids
Salinity
Specific gravity } = Must be enabled

Order EC,TDS,SAL,SG
Encoding ASCII

Format

string

Data type

floating point

Decimal places

3

Smallest string

3 characters

Largest string

40 characters

Sending commands to device


5 parts




Example

Start 100 (0x64) Write Sleep Stop



I²C address Command




Advanced



Requesting data from device



Advanced




1 49 44 52 49 51 0 = 1,413
Dec Dec
ASCII

Response codes

After a command has been issued, a 1 byte response code can be read in order to confirm that the command was processed successfully.

Reading back the response code is completely optional, and is not required for normal operation.



Example

```
I2C_start;  
I2C_address;  
I2C_write(EZO_command);  
I2C_stop;
```

```
delay(300);
```



Processing delay

```
I2C_start;  
I2C_address;  
Char[ ] = I2C_read;  
I2C_stop;
```


The response code will always be 254, if you do not wait for the processing delay.

Response codes

Single byte, not string


255	no data to send
254	still processing, not ready
2	syntax error
1	successful request

LED color definition




Blue

I²C standby




Green

Taking reading




Purple

Changing
I²C address



Red


Command
not understood



White

Find

5V	LED ON +2.5 mA
3.3V	+1 mA



Solid Green LED

in UART mode
Not I²C ready

I²C mode

command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	
Baud	switch back to UART mode	pg. 63
Cal	performs calibration	pg. 49
Export	export calibration	pg. 51
Factory	enable factory reset	pg. 62
Find	finds device with blinking white LED	pg. 47
i	device information	pg. 57
I2C	change I ² C address	pg. 61
Import	import calibration	pg. 52
K	set probe type	pg. 53
L	enable/disable LED	pg. 46
Name	set/show name of device	pg. 56
O	enable/disable parameters	pg. 55
Plock	enable/disable protocol lock	pg. 60
R	returns a single reading	pg. 48
Sleep	enter sleep mode/low power	pg. 59
Status	retrieve status information	pg. 58
T	temperature compensation	pg. 54
TDS	change the TDS conversion factor	pg. 50

LED control

Command syntax

300ms  processing delay

L,1 LED on **default**

L,0 LED off

L,? LED state on/off?

Example

L,1


Wait 300ms

1
Dec
0
Null

L,0


Wait 300ms

1
Dec
0
Null


L,?


Wait 300ms


1
Dec
?L,1
ASCII
0
Null

or

1
Dec
?L,0
ASCII
0
Null



L,1



L,0

Find

300ms  processing delay

Command syntax




This command will disable continuous mode
Send any character or command to terminate find.

Find LED rapidly blinks white, used to help find device

Example Response

Find

 Wait 300ms
1 Dec **0** Null



Taking reading

Command syntax

600ms  processing delay

R return 1 reading


Example

Response

R



Wait 600ms

1	1,413	0
Dec	ASCII	Null




Green

Taking reading



Transmitting



Blue

Standby

Calibration

Command syntax

600ms  processing delay

Dry calibration must always be done first!

Cal,dry	dry calibration
Cal,n	single point calibration, where n = any value
Cal,low,n	low end calibration, where n = any value
Cal,high,n	high end calibration, where n = any value
Cal,clear	delete calibration data
Cal,?	device calibrated?

Example

Response

Cal,dry

 Wait 600ms **1** **0**
Dec Null

Cal,84

 Wait 600ms **1** **0**
Dec Null

Cal,low,12880

 Wait 600ms **1** **0**
Dec Null

Cal,high,80000

 Wait 600ms **1** **0**
Dec Null

Cal,clear

 Wait 300ms **1** **0**
Dec Null

Cal,?

 Wait 300ms **1** **?CAL,0** **0** or **1** **?CAL,1** **0** or **1** **?CAL,2** **0**
Dec ASCII Null Dec ASCII Null Dec ASCII Null

Two point calibration:

Step 1. "cal,dry"

Step 2. "cal,n"

Calibration complete!

Three point calibration:

Step 1 "cal,dry"

Step 2 "cal,low,n"

Step 3 "cal,high,n"

Calibration complete!

Changing the TDS (ppm) conversion factor

300ms  processing delay

Command syntax

There are several different conversion factors used to read TDS(ppm). For some applications, it may be necessary to use a conversion factor other than the default value of 0.54

TDS,n	set custom conversion factor, n = any value between 0.01 – 1.00
TDS,?	conversion factor being used

Example	Response
TDS,?	 Wait 300ms 1 Dec ?TDS,0.54 0 Null
R	 Wait 300ms 1 Dec 100,54 0 Null EC ↓ TDS ↓
TDS,0.46	 Wait 300ms 1 Dec 0 Null
R	 Wait 300ms 1 Dec 100,46 0 Null EC ↓ TDS ↓

Common conversion factors	
NaCl	0.47 – 0.50
KCL	0.50 - 0.57
"442"	0.65 – 0.85

Formula
 $EC \times \text{conversion factor} = \text{TDS}$

Export calibration

300ms  processing delay

Command syntax

Export: Use this command to download calibration settings

Export,? calibration string info

Export export calibration string from calibrated device

Example

Export,?

Response



Wait 300ms

1 10,120 0
Dec ASCII Null

Response breakdown

10, 120

of strings to export # of bytes to export

Export strings can be up to 12 characters long

Export



Wait 300ms

1 59 6F 75 20 61 72 0
Dec ASCII Null

(1 of 10)

Export



Wait 300ms

1 65 20 61 20 63 6F 0
Dec ASCII Null

(2 of 10)

(7 more)

⋮

Export



Wait 300ms

1 6F 6C 20 67 75 79 0
Dec ASCII Null

(10 of 10)

Export



Wait 300ms

1 *DONE 0
Dec ASCII Null

Import calibration

300ms  processing delay

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n import calibration string to new device

Example

Import, 59 6F 75 20 61 72

(1 of 10)

Import, 65 20 61 20 63 6F

(2 of 10)

⋮

Import, 6F 6C 20 67 75 79

(10 of 10)




Response

 1 0 Null
Wait 300ms

 1 0 Null
Wait 300ms


⋮
 1 0 Null
Wait 300ms

Import,n



1 *Pending 0
Dec ASCII Null

system will reboot



* If one of the imported strings is not correctly entered, the device will not accept the import and reboot.

Setting the probe type

Command syntax

300ms  processing delay

K,n n = any value; floating point in ASCII

K 1.0 is the default value

K,? probe K value?

Example

Response

K,10

 Wait 300ms
1 Dec 0 Null

K,?

 Wait 600ms
1 Dec K,10 ASCII 0 Null



K 0.1



K 1.0



K 10

Temperature compensation

Command syntax

Default temperature = 25°C
Temperature is always in Celsius
Temperature is not retained if power is cut

- T,n n = any value; floating point or int 300ms  processing delay
- T,? compensated temperature value?
- RT,n set temperature compensation and take a reading

Example

T,19.5


Wait 300ms

1	0
Dec	Null

RT,19.5



Wait 900ms

1	8.91	0
Dec	ASCII	Null

T,?


Wait 300ms

1	?T,19.5	0
Dec	ASCII	Null



Enable/disable parameters from output string

Command syntax

300ms  processing delay

O, [parameter],[1,0]

enable or disable output parameter
enabled parameter?

Example

O,EC,1 / O,EC,0

Response

 Wait 300ms	1	Dec	0	enable / disable conductivity
 Wait 300ms	1	Dec	0	enable / disable total dissolved solids
 Wait 300ms	1	Dec	0	enable / disable salinity
 Wait 300ms	1	Dec	0	enable / disable specific gravity
O,?	1	Dec	? ,O,EC,TDS,S,SG	0 ASCII Null if all are enabled

Parameters

EC Conductivity = $\mu\text{S}/\text{cm}$

TDS Total dissolved solids = ppm

S Salinity = PSU (ppt) 0.00 – 42.00

SG Specific gravity (sea water only) = 1.00 – 1.300

* If you disable all possible data types
your readings will display "no output".

Followed by 1 or 0

1 enabled

0 disabled

Naming device

300ms  processing delay

Command syntax

Do not use spaces in the name

Name,n set name

n =

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Name, clears name

Up to 16 ASCII characters

Name,? show name

Example

Response

Name,



1
Dec
0
Null

name has been cleared

Name,zzt




1
Dec
0
Null

Name,?




1
Dec
?Name,zzt
ASCII
0
Null

Name,zzt



Name,?



1 0

1 ?Name,zzt 0

Device information

Command syntax

300ms  processing delay

i device information

Example

Response

i



Wait 300ms

1

Dec

?i,EC, 2.16

ASCII

0

Null

Response breakdown

?i, EC, 2.16

Device

Firmware

Reading device status

Command syntax

300ms  processing delay

Status voltage at Vcc pin and reason for last restart

Example Response

Status



Wait 300ms

1

?Status,P,5.038

Dec

ASCII

0

Null

Response breakdown

?Status, P,
Reason for restart 5.038
 Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Sleep mode/low power

Command syntax

Sleep enter sleep mode/low power

Send any character or command to awaken device.

Example

Response

Sleep

no response


Do not read status byte after issuing sleep command.

Any command


wakes up device

	STANDBY	SLEEP
5V	18.14 mA	0.7 mA


3.3V	16.85 mA	0.4 mA
-------------	-----------------	---------------



Standby



Sleep



Sleep

Protocol lock

Command syntax

300ms  processing delay

Plock,1 enable Plock

Locks device to I²C mode.

Plock,0 disable Plock

default

Plock,? Plock on/off?

Example

Plock,1

 Wait 300ms

1
Dec
0
Null

Plock,0


 Wait 300ms

1
Dec
0
Null


Plock,?

 Wait 300ms


1
Dec
?Plock,1
ASCII
0
Null



Baud, 9600



cannot change to UART



cannot change to UART

I²C address change

Command syntax

300ms  processing delay

I²C,n sets I²C address and reboots into I²C mode

Example Response

I²C,101

device reboot

(no response given)



Warning!

Changing the I²C address will prevent communication between the circuit and the CPU until your CPU is updated with the new I²C address.


Default I²C address is 100 (0x64).

n = any number 1 – 127

I²C,101



(reboot)



Factory reset

Command syntax

Factory reset will not take the device out of I²C mode.

Factory enable factory reset

I²C address will not change

Example Response



Factory

device reboot


(no response given)

Clears calibration
LED on
Response codes enabled

Factory



(reboot)



Change to UART mode

Command syntax

Baud,n switch from I²C to UART

Example



Baud,9600

Response



reboot in UART mode

(no response given)

n = [300
1200
2400
9600
19200
38400
57600
115200]




Baud,9600



(reboot)


Changing to
UART mode




Manual switching to UART

- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to the right PRB
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Blue to Green
- Disconnect ground (power off)
- Reconnect all data and power

Example



Wrong Example



Calibration theory

The accuracy of your readings is directly related to the quality of your calibration.
(Calibration is not difficult, and a little bit of care goes a long way)

A properly calibrated conductivity probe will never need recalibration. Once calibrated, you can use the probe continuously year after year without concern. This is because a conductivity probe does not contain any parts that wear out over time.

However, changing the cable length of the probe or moving the EZO-EC circuit from one machine to another may require recalibration. This is because such actions will change the electrical properties of the probe or EC circuit.




Two point or Three point calibration


No calibration




Two point calibration



Three point calibration



Recommended calibration points




When calibrating, Atlas Scientific recommends using the above μS values. However, you can use any μS values you want.

Temperature compensation during calibration


Temperature has a significant effect on conductivity readings. The EZO™ Conductivity circuit has its temperature compensation set to 25° C as the default. **At no point should you change the default temperature compensation during calibration.**

If the solution is +/- 5° C (or more), refer to the chart on the bottle, and calibrate to that value.




Temperature compensation example

For this example, we brought the temperature of the solution down to 10° C. Referring to chart on the bottle, you can see the value you should calibrate to is **9,330µS**.




Over time, the readings will normalize as the solution warms to 25° C.

See pages **27** or **54** for more information.



1. Pre-calibration setup

Connect the dry conductivity probe and take continuous readings.



2. Set probe type

If your probe \neq K 1.0 (*default*), then set the probe type by using the "**K,n**" command.
(where $n = K$ value of your probe) for more information, see page [26](#) or [53](#).

3. Dry calibration

Perform a dry calibration using the command "**Cal,dry**". Even though you may see readings of 0.00 before issuing the "**Cal,dry**" command, it is still a necessary part of calibration.

00.00 → "Cal,dry" → 0.00 ✓ Correct

17.00 → "Cal,dry" → 0.00 ✓ Also correct



4. Calibration

Atlas Scientific recommends performing a three point calibration (*dry, low point & high point*) to obtain the greatest sensing range possible. However, depending on your situation a two point calibration may suffice.

To perform a two or three point calibration, follow the instructions below.

Two point calibration


After completing the dry calibration; Pour a small amount of calibration solution into a cup (μS value of your choice). Shake the probe to make sure you do not have trapped air in the probe. You should see readings that are off by $+\/- 40\%$ from the stated value of the calibration solution. Wait for readings to stabilize (*small movement from one reading to the next is normal*).



Calibration complete!

Three point calibration - low point


- Complete the dry calibration process first.
- Pour a small amount of the low point calibration solution into a cup.
- Shake the probe to remove trapped air.
- Readings may be off by +/- 40%
- Wait for readings to stabilize.



Once the readings stabilize, issue the low point calibration command: "**cal,low,12880**"
(Readings will **NOT** change)

Three point calibration - high point

- Rinse off the probe before calibrating to the high point.
- Pour a small amount of the high point calibration solution into a cup.
- Shake the probe to remove trapped air.
- Readings may be off by +/- 40%
- Wait for readings to stabilize.




Once the readings stabilize, issue the high point calibration command: "**cal,high,80000**"
(Readings **will** change, calibration complete).

Calibration complete!


Best practices for calibration

Always watch the readings throughout the calibration process.
Issue calibration commands once the readings have stabilized.





⚠ Never do a blind calibration! ⚠

Issuing a calibration command before the readings stabilize will result in drifting readings.



Long-term conductivity measurements in stagnant water

Taking continuous conductivity readings in stagnant water:



A small amount of energy must be put into the water to measure conductivity. This small amount of energy will start to affect the readings in stagnant water. Over time, the energy passing through the stagnant water will start to align the dissolved salts along a path of least resistance. Lowering the resistance of the water will increase the water's conductivity.


Moving the probe or the water will disrupt this alignment and cause the readings to suddenly return to normal.

***These are example readings; there is no way to predict how the readings will change over time.**

Soldering


Do not directly solder an EZO circuit to your PCB. If something goes wrong during the soldering process it may become impossible to correct the problem. It is simply not worth the risk.

Instead, solder female header pins to your PCB and place the EZO device in the female headers.



**Avoid using rosin core solder.
Use as little flux as possible.**

Flux residue will severely affect your readings. Any Flux residue that comes in contact with the PRB pins or your probes connector will cause a "flux short".




You **MUST** remove all the flux residue from your PCB after soldering.

Soldering

Removing flux residue can be done with commercially available products such as flux off or you can use alcohol and a tooth brush.



Remove EZO Circuit and soak in alcohol for 10 mins.




Bush with tooth brush.



Soak in alcohol for 5 mins.



Let it dry in the air.






DONE


What does a flux short look like?

Readings move slowly and take serval minutes to reach the correct value.


EZO™ circuit footprint




1 In your CAD software,
place a 8 position header.



2 Place a 3 position header at both
top and bottom of the 8 position.



3 Delete the 8 position header. The two 3
position headers are now 17.78mm (0.7")
apart from each other.



Datasheet change log

Datasheet V 6.5

Revised calibration theory on pages 65 - 70.

Datasheet V 6.4

Revised entire document.

Datasheet V 6.3

Revised naming device info on pages 36 & 63.

Datasheet V 6.2

Added new command:

"TDS,n" Changing the TDS (ppm) conversion factor on pages 30 (UART) & 57 (I²C).

Datasheet V 6.1

Corrected typos within the datasheet.

Datasheet V 6.0

Changed the K value range from 0.1 to 0.01 on pg 5.

Datasheet V 5.9

Moved Default state to pg 17.

Datasheet V 5.8

Revised conductivity probe range information on pg 5.

Datasheet V 5.7

Revised response for the sleep command in UART mode on pg 39.

Datasheet V 5.6

Added more information on the Export calibration and Import calibration commands.

Datasheet V 5.5

Revised calibration theory pages, added information on temperature compensation on pg. 15, moved data isolation to pg 9, and correct wiring to pg 11.

Datasheet V 5.4

Revised isolation schematic on pg. 13

Datasheet V 5.3

Added new command:

"RT,n" for Temperature compensation located on pages 30 (UART) & 55 (I²C).
Added firmware information to Firmware update list.

Datasheet V 5.2

Revised calibration information on pages 27 & 52.

Datasheet V 5.1

Added more information about temperature compensation on pages 30 & 55.

Datasheet V 5.0

Changed "Max rate" to "Response time" on cover page.

Datasheet V 4.9

Removed note from certain commands about firmware version.
Added steps to calibration command pages 27 (UART) and 52 (I²C).

Datasheet V 4.8

Revised definition of response codes on pg 46.

Datasheet V 4.7

Revised cover page art.

Datasheet V 4.6

Updated calibration processing delay time on pg.52.

Datasheet V 4.5

Revised Enable/disable parameters information on pages 31 & 56.

Datasheet V 4.4

Updated High point calibration info on page 11.

Datasheet V 4.3

Updated calibration info on pages 27 (UART) and 52 (I²C).

Datasheet V 4.2

Revised Plock pages to show default value.

Datasheet V 4.1

Corrected I²C calibration delay on pg. 52.

Datasheet V 4.0

Revised entire datasheet.

Firmware updates

V1.0 – Initial release (April 17, 2014)

V1.1 – (June 2, 2014)

- Change specific gravity equation to return 1.0 when the uS reading is < 1000 (previously returned 0.0)
- Change accuracy of specific gravity from 2 decimal places to 3 decimal places
- Don't save temperature changes to EEPROM

V1.2 – (Aug 1, 2014)

- Baud rate change is now a long, purple blink

V1.5 – Baud rate change (Nov 6, 2014)

- Change default baud rate to 9600

V1.6 – I²C bug (Dec 1, 2014)

- Fixed I²C bug where the circuit may inappropriately respond when other I²C devices are connected

V1.8 – Factory (April 14, 2015)

- Changed "X" command to "Factory"

V1.95 – Plock (March 31, 2016)

- Added protocol lock feature "Plock"

V1.96 – EEPROM (April 26, 2016)

- Fixed bug where EEPROM would get erased if the circuit lost power 900ms into startup
This would cause the EZO circuit to revert back to UART mode if set to I²C

V2.10 – (April 12, 2017)

- Added "Find" command.
- Added "Export/import" command.
- Modified continuous mode to be able to send readings every "n" seconds.
- Default output changed from CSV string of 4 values to just conductivity; Other values must be enabled

V2.11 – (April 28, 2017)

- Fixed "Sleep" bug, where it would draw excessive current.

V2.12 – (May 9, 2017)

- Fixed bug in sleep mode, where circuit would wake up to a different I²C address.

V2.13 – (July 16, 2018)

- Added "RT" command to Temperature compensation

V2.14 – (Nov 26, 2019)

- The K value range has been extended to 0.01

V2.15 – (June 29, 2020)

- Fixed bug where output doesn't always round to 0

Firmware updates

V2.16 – (Dec 14, 2021)

- Internal update for new part compatibility.

Warranty

Atlas Scientific™ Warranties the EZO™ class Conductivity circuit to be free of defect during the debugging phase of device implementation, or 30 days after receiving the EZO™ class Conductivity circuit (which ever comes first).

The debugging phase

The debugging phase as defined by Atlas Scientific™ is the time period when the EZO™ class Conductivity circuit is inserted into a bread board, or shield. If the EZO™ class Conductivity circuit is being debugged in a bread board, the bread board must be devoid of other components. If the EZO™ class Conductivity circuit is being connected to a microcontroller, the microcontroller must be running code that has been designed to drive the EZO™ class Conductivity circuit exclusively and output the EZO™ class Conductivity circuit data as a serial string.

It is important for the embedded systems engineer to keep in mind that the following activities will void the EZO™ class Conductivity circuit warranty:

- **Soldering any part of the EZO™ class Conductivity circuit.**
- **Running any code, that does not exclusively drive the EZO™ class Conductivity circuit and output its data in a serial string.**
- **Embedding the EZO™ class Conductivity circuit into a custom made device.**
- **Removing any potting compound.**

Reasoning behind this warranty

Because Atlas Scientific™ does not sell consumer electronics; once the device has been embedded into a custom made system, Atlas Scientific™ cannot possibly warranty the EZO™ class Conductivity circuit, against the thousands of possible variables that may cause the EZO™ class Conductivity circuit to no longer function properly.

Please keep this in mind:

- 1. All Atlas Scientific™ devices have been designed to be embedded into a custom made system by you, the embedded systems engineer.**
- 2. All Atlas Scientific™ devices have been designed to run indefinitely without failure in the field.**
- 3. All Atlas Scientific™ devices can be soldered into place, however you do so at your own risk.**

Atlas Scientific™ is simply stating that once the device is being used in your application, Atlas Scientific™ can no longer take responsibility for the EZO™ class Conductivity circuits continued operation. This is because that would be equivalent to Atlas Scientific™ taking responsibility over the correct operation of your entire device.

EZO-DO™

Embedded Dissolved Oxygen Circuit

ISO 5814 Compliant

(determination of dissolved oxygen)

Reads

Dissolved Oxygen

0.00 – 100 mg/L

0 – 350% saturation

+/- 0.05 mg/L

D.O. reading time

600ms

Supported probes

Any galvanic probe

Calibration

1 or 2 point

Temperature, salinity
and pressure compensation

Yes

Data protocol

UART & I²C

Default I²C address


97 (0x61)

Operating voltage


3.3V – 5V

Data format




ASCII



The EZO™ D.O. Circuit has all the features of this bench top meter.



Isolated Power Supply



- 1 Two decimal D.O. reading
- 2 Temperature, pressure, and salinity compensation value
- 3 Percent saturation
- 4 Milligrams per liter
- 5 Immediate reading
- 6 Timed readings

- 7 Set device name
- 8 Voltage usage
- 9 Multi point calibration
- 10 Manual temperature compensation
- 11 Manual pressure compensation
- 12 Manual salinity compensation

The EZO™ D.O. Circuit is compatible with any brand of galvanic D.O. probe.

 Available data protocols

UART

Default

I²C

 Unavailable data protocols

SPI

Analog

RS-485

Mod Bus

4–20mA

STOP




SOLDERING THIS DEVICE VOIDS YOUR WARRANTY.

Are there specific soldering instructions? Yes, see page 71.

Can you make a warranty claim after soldering? No.

If you have not used this product before; Observe how a properly working sensor behaves **BEFORE** embedding it into your PCB.

Get this device working using one of these methods first.



Do not embed before you have experience with this sensor.




Table of contents

Available data protocols	3	Correct wiring	9
Circuit dimensions	6	Default state	10
Power consumption	6	Circuit footprint	73
Absolute max ratings	6	Datasheet change log	74
Electrical isolation	7	Warranty	79
Calibration theory	63		
Understanding D.O. measurements	68		
Hyper saturation with pure oxygen	70		


UART

UART mode	11
LED color definition	12
Receiving data from device	13
Sending commands to device	14
UART quick command page	15
LED control	16
Find	17
Continuous reading mode	18
Single reading mode	19
Calibration	20
Export calibration	21
Import calibration	22
Temperature compensation	23
Salinity compensation	24
Atmospheric pressure compensation	25
Enable/disable parameters	26
Naming device	27
Device information	28
Response codes	29
Reading device status	30
Sleep mode/low power	31
Change baud rate	32
Protocol lock	33
Factory reset	34
Change to I ² C mode	35
Manual switching to I ² C	36

I²C

I ² C mode	38
Sending commands	39
Requesting data	40
Response codes	41
LED color definition	42
I ² C quick command page	43
LED control	44
Find	45
Taking reading	46
Calibration	47
Export calibration	48
Import calibration	49
Temperature compensation	50
Salinity compensation	51
Atmospheric pressure compensation	52
Enable/disable parameters	53
Naming device	54
Device information	55
Reading device status	56
Sleep mode/low power	57
Protocol lock	58
I ² C address change	59
Factory reset	60
Change to UART mode	61
Manual switching to UART	62

EZO™ circuit dimensions



Power consumption

Absolute max ratings

	LED	MAX	STANDBY	SLEEP
5V	ON	13.5 mA	13.1 mA	0.66 mA
	OFF	12.7 mA	12.7 mA	
3.3V	ON	12.1 mA	12 mA	0.3 mA
	OFF	11.9 mA	11.9 mA	

Parameter	MIN	TYP	MAX
Storage temperature (EZO™ D.O.)	-65 °C		125 °C
Operational temperature (EZO™ D.O.)	-40 °C	25 °C	85 °C
VCC	3.3V	5V	5.5V

Electrical isolation

The Atlas Scientific EZO™ Dissolved Oxygen circuit is a very sensitive device. This sensitivity is what gives the Dissolved Oxygen circuit its accuracy. This also means that the Dissolved Oxygen circuit is capable of reading micro-voltages that are bleeding into the water from unnatural sources such as pumps, solenoid valves or other probes/sensors.

When electrical noise is interfering with the Dissolved Oxygen readings it is common to see rapidly fluctuating readings or readings that are consistently off. To verify that electrical noise is causing inaccurate readings, place the Dissolved Oxygen probe in a cup of water by itself. The readings should stabilize quickly, confirming that electrical noise was the issue.



Advice:

When reading D.O. along with other sensors, electrical isolation is strongly recommended.
Never build a commercial product without electrical isolation.


Atlas Scientific offers several different electrical isolation products that can be used in your design. Select the electrical isolation product that works best for your design.



Basic EZO™
Inline Voltage Isolator



Vertical Isolator



Electrically Isolated
EZO™ Carrier Board



Gen 2 Electrically Isolated
USB EZO™ Carrier Board



Whitebox T1



Whitebox T3



Whitebox T3




Electrically Isolated EZO™
Carrier Board (old style)

For various reasons, you may need to build your own electrical isolator. Because electrical isolation is so important, we have published our isolation schematic for anyone to use.


This isolation schematic is based on the ADM3260, which can output up to 150 mW of isolated power. PCB layout requires special attention for EMI/EMC and RF Control. Having good ground planes and keeping the capacitors as close to the chip as possible are crucial for proper performance.

The two data channels have a $4.7\text{k}\Omega$ pull-up resistor on both the isolated and non-isolated lines (R1, R2, R3, and R4). The output voltage is set using a voltage divider (R5, R6, and R7). This produces a voltage of 3.9V regardless of your input voltage.


Isolated ground is different from non-isolated ground, these two lines should not be connected together.




✓ Correct wiring




Bread board




Bread board via USB



Non-Isolated
EZO™ Carrier Board



Electrically Isolated
EZO™ Carrier Board




USB
carrier board

✗ Incorrect wiring


Extended leads




Sloppy setup



Perfboards or Protoboards



*Embedded into your device





NEVER
use Perfboards or Protoboards

Flux residue and shorting wires make
it very hard to get accurate readings.

*Only after you are familiar
with EZO™ circuits operation

Default state UART mode

Baud	9,600
Readings	continuous
Units	mg/L
Speed	1 reading per second
LED	on



**Solid Blue LED
in I²C mode
Not UART ready**

UART mode

8 data bits no parity
1 stop bit no flow control


Baud 300
1,200
2,400
9,600 default
19,200
38,400
57,600
115,200

RX Data in

TX Data out

Vcc 3.3V – 5.5V

0V VCC 0V



Data format

Reading D.O.

Order mg/L & (% sat)
when enabled

Encoding ASCII

Format string
(CSV string when % sat is enabled)

Terminator carriage return

Data type

Decimal places

Smallest string

Largest string


floating point

mg/L = 2
% sat = 1


4 characters

40 characters


LED color definition




Green
UART standby




Cyan
Taking reading




Purple
Changing baud rate



Red
Command not understood



White
Find



Blue
I2C standby

5V	LED ON +0.4 mA
3.3V	+0.2 mA

Settings that are retained if power is cut


- Baud rate
- Calibration
- Continuous mode
- Device name
- Enable/disable parameters
- Enable/disable response codes
- Hardware switch to I²C mode
- LED control
- Protocol lock
- Software switch to I²C mode

Settings that are **NOT** retained if power is cut

- Find
- Pressure compensation
- Salinity compensation
- Sleep mode
- Temperature compensation

Receiving data from device

2 parts



Advanced


ASCII: 7 . 8 2 <cr>

Hex: 37 2E 38 32 0D

Dec: 55 46 56 50 13

Sending commands to device

2 parts



Advanced

ASCII:

S	I	e	e	p	<cr>
---	---	---	---	---	------

Hex:

53	6C	65	65	70	0D
----	----	----	----	----	----

Dec:

83	108	101	101	112	13
----	-----	-----	-----	-----	----

UART mode

command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	Default state
Baud	change baud rate	pg. 32 9,600
C	enable/disable continuous reading	pg. 18 enabled
Cal	performs calibration	pg. 20 n/a
Export	export calibration	pg. 21 n/a
Factory	enable factory reset	pg. 34 n/a
Find	finds device with blinking white LED	pg. 17 n/a
i	device information	pg. 28 n/a
I2C	change to I ² C mode	pg. 35 not set
Import	import calibration	pg. 22 n/a
L	enable/disable LED	pg. 16 enabled
Name	set/show name of device	pg. 27 not set
O	enable/disable parameters	pg. 26 mg/L
P	atmospheric pressure compensation	pg. 25 101.3 kPa
Plock	enable/disable protocol lock	pg. 33 disabled
R	returns a single reading	pg. 19 n/a
S	salinity compensation	pg. 24 n/a
Sleep	enter sleep mode/low power	pg. 31 n/a
Status	retrieve status information	pg. 30 n/a
T	temperature compensation	pg. 23 20°C
*OK	enable/disable response codes	pg. 29 enable

LED control

Command syntax

L,1 <cr> LED on **default**

L,0 <cr> LED off

L,? <cr> LED state on/off?

Example

L,1 <cr>

*OK <cr>

L,0 <cr>


*OK <cr>

L,? <cr>


?L,1 <cr> or ?L,0 <cr>

*OK <cr>

Response



L,1



L,0

Find

Command syntax


This command will disable continuous mode
Send any character or command to terminate find.

Find <cr> LED rapidly blinks white, used to help find device

Example Response

Find <cr>

*OK <cr>



Continuous reading mode

Command syntax

- C,1 <cr> enable continuous readings once per second **default**
C,n <cr> continuous readings every n seconds (n = 2 to 99 sec)
C,0 <cr> disable continuous readings
C,? <cr> continuous reading mode on/off?

Example Response

C,1 <cr>	*OK <cr> DO (1 sec) <cr> DO (2 sec) <cr> DO (3 sec) <cr>
C,30 <cr>	*OK <cr> DO (30 sec) <cr> DO (60 sec) <cr> DO (90 sec) <cr>
C,0 <cr>	*OK <cr>
C,? <cr>	?C,1 <cr> or ?C,0 <cr> or ?C,30 <cr> *OK <cr>

Single reading mode

Command syntax


R <cr> takes single reading

Example Response


R <cr>

7.82 <cr>


*OK <cr>



Green
Standby



Cyan
Taking reading



Transmitting



Calibration

Command syntax

The EZO™ Dissolved Oxygen circuit uses single and/or two point calibration


Cal	<cr> calibrate to atmospheric oxygen levels
Cal,0	<cr> calibrate device to 0 dissolved oxygen
Cal,clear	<cr> delete calibration data
Cal,?	<cr> device calibrated?

Example Response

Cal <cr>	*OK <cr>
Cal,0 <cr>	*OK <cr>
Cal,clear <cr>	*OK <cr>
Cal,? <cr>	?Cal,0 <cr> or ?Cal,1 <cr> or ?Cal,2 <cr> *OK <cr>

single point

two point



Export calibration

Command syntax

Export: Use this command to download calibration settings

Export,? <cr> calibration string info

Export <cr> export calibration string from calibrated device

Example

Export,? <cr>

Response

10,120 <cr>

Response breakdown

10, 120

of strings to export

of bytes to export

Export strings can be up to 12 characters long,
and is always followed by <cr>

Export <cr>

59 6F 75 20 61 72 <cr> (1 of 10)

Export <cr>

65 20 61 20 63 6F <cr> (2 of 10)

(7 more)

⋮

Export <cr>




6F 6C 20 67 75 79 <cr> (10 of 10)

Export <cr>

*DONE

Disabling *OK simplifies this process

Export <cr>



Import calibration

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n <cr> import calibration string to new device

Example

Import, 59 6F 75 20 61 72 <cr> (1 of 10)

Import, 65 20 61 20 63 6F <cr> (2 of 10)

⋮

Import, 6F 6C 20 67 75 79 <cr> (10 of 10)

Response




*OK <cr>

*OK <cr>

⋮


*OK <cr>

Import,n <cr>



*OK <cr>

system will reboot



*ER <cr>

* If one of the imported strings is not correctly entered, the device will not accept the import, respond with *ER and reboot.

Temperature compensation

Command syntax

Default temperature = 20°C
Temperature is always in Celsius
Temperature is not retained if power is cut

T,n <cr> n = any value; floating point or int

T,? <cr> compensated temperature value?

RT,n <cr> set temperature compensation and take a reading*

This is a new command
for firmware V2.13

Example

T,19.5 <cr>

Response


*OK <cr>

RT,19.5 <cr>

*OK <cr>
8.91 <cr>

T,? <cr>

?T,19.5 <cr>
*OK <cr>



Salinity compensation

Command syntax

Default value = 0 μs

If the conductivity of your water is less than 2,500 μS this command is irrelevant

S,n <cr> n = any value in microsiemens

S,n,ppt <cr> n = any value in ppt

S,? <cr> compensated salinity value?

Example

S,50000 <cr>

*OK <cr>

S,37.5,ppt <cr>


*OK <cr>

S,? <cr>

?S,50000, μS <cr> or ?S,37.5,ppt <cr>

*OK <cr>

Response



Atmospheric pressure compensation

Command syntax

P,n <cr> n = any value in kPa

P,? <cr> compensated pressure value?

Example


P,90.25 <cr>

Response

*OK <cr>

P,? <cr>

?P,90.25 <cr>
*OK <cr>



Enable/disable parameters from output string

Command syntax

O, [parameter],[1,0] <cr> enable or disable output parameter
O,? <cr> enabled parameter?

Example

O,mg,1 / O,mg,0 <cr>

Response

*OK <cr> enable / disable mg/L

O,%,1 / O,%,0 <cr>

*OK <cr> enable / disable percent saturation

O,? <cr>

? ,O,%,mg <cr> if both are enabled

Parameters

mg mg/L

% percent saturation

Followed by 1 or 0

1 enabled

0 disabled

* If you disable all possible data types
your readings will display "no output".

Naming device

Command syntax

Do not use spaces in the name

Name,n <cr> set name

n = 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Name, <cr> clears name

Up to 16 ASCII characters

Name,? <cr> show name

Example

Response

Name, <cr>

*OK <cr> name has been cleared

Name,zzt <cr>


*OK <cr>

Name,? <cr>


?Name,zzt <cr>

*OK <cr>

Name,zzt



Name,?



*OK <cr>

?Name,zzt <cr>

*OK <cr>

Device information

Command syntax

i <cr> device information

Example Response

i <cr>

?i,D.O.,1.98 <cr>
*OK <cr>

Response breakdown

?i, D.O., 1.98
↑ ↑
Device Firmware

Response codes

Command syntax

*OK,1 <cr> enable response **default**
*OK,0 <cr> disable response
*OK,? <cr> response on/off?

Example

R <cr>

7.82 <cr>

***OK <cr>**

***OK,0 <cr>**

no response, *OK disabled

R <cr>

7.82 <cr> *OK disabled

***OK,? <cr>**

?*OK,1 <cr> or ?*OK,0 <cr>

Response

Other response codes

*ER unknown command
*OV over volt (VCC>=5.5V)
*UV under volt (VCC<=3.1V)
*RS reset
*RE boot up complete, ready
*SL entering sleep mode
*WA wake up

These response codes
cannot be disabled

Reading device status

Command syntax

Status <cr> voltage at Vcc pin and reason for last restart

Example Response

Status <cr>

?Status,P,5.038 <cr>

*OK <cr>

Response breakdown

?Status, P, 5.038
↑ ↑
Reason for restart Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Sleep mode/low power

Command syntax

Send any character or command to awaken device.

Sleep <cr> enter sleep mode/low power

Example

Sleep <cr>


***OK <cr>**

***SL <cr>**

Any command

***WA <cr> wakes up device**


	STANDBY	SLEEP
5V	13.1 mA	0.66 mA
3.3V	12 mA	0.3 mA



Standby
13.1 mA



Sleep <cr>



Sleep
0.66 mA

Change baud rate

Command syntax

Baud,n <cr> change baud rate

Example

Baud,38400 <cr>

Response


*OK <cr>

Baud,? <cr>

?Baud,38400 <cr>

*OK <cr>


n = [300
1200
2400
9600 default
19200
38400
57600
115200]



Standby



Baud,38400 <cr>




Changing
baud rate

*OK <cr>



(reboot)



Standby

Protocol lock

Command syntax

Locks device to UART mode.

Plock,1 <cr> enable Plock

Plock,0 <cr> disable Plock **default**

Plock,? <cr> Plock on/off?

Example

Plock,1 <cr>

*OK <cr>


Plock,0 <cr>

*OK <cr>

Plock,? <cr>


?Plock,1 <cr> or ?Plock,0 <cr>

Response



*OK <cr>


I2C,100



cannot change to I²C

*ER <cr>

Short



cannot change to I²C

Factory reset

Command syntax

Clears calibration
LED on
"*OK" enabled


Factory <cr> enable factory reset

Example Response


Factory <cr>

*OK <cr>

Factory <cr>



(reboot)



*OK <cr>

*RS <cr>

*RE <cr>

Baud rate will not change

Change to I²C mode

Command syntax

Default I²C address 97 (0x61)

I²C,n <cr> sets I²C address and reboots into I²C mode

n = any number 1 – 127

Example Response

I²C,100 <cr>

*OK (reboot in I²C mode)



Wrong example

I²C,139 <cr> n > 127


Response

*ER <cr>

I²C,100



(reboot)



Green
*OK <cr>


Blue
now in I²C mode

Manual switching to I²C


- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to PGND
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Green to Blue
- Disconnect ground (power off)
- Reconnect all data and power

Manually switching to I²C will set the I²C address to 97 (0x61)

Example



Wrong Example



I²C mode

The I²C protocol is **considerably more complex** than the UART (RS-232) protocol. Atlas Scientific assumes the embedded systems engineer understands this protocol.

To set your EZO™ device into I²C mode [click here](#)

Settings that are retained if power is cut

- Calibration
- Change I²C address
- Enable/disable parameters
- Hardware switch to UART mode
- LED control
- Protocol lock
- Software switch to UART mode

Settings that are **NOT** retained if power is cut

- Find
- Pressure compensation
- Salinity compensation
- Sleep mode
- Temperature compensation



I²C mode

I²C address (0x01 – 0x7F)

97 (0x61) default

V_{cc} 3.3V – 5.5V

Clock speed 100 – 400 kHz



Data format


Reading	Dissolved Oxygen	Data type	floating point
Order	mg/L & (% sat) <small>when enabled</small>	Decimal places	mg/L = 2 % sat = 1
Encoding	ASCII	Smallest string	4 characters
Format	string <small>(CSV string when % sat is enabled)</small>	Largest string	16 characters

Sending commands to device




Example



Start **97 (0x61)** **Write** **Sleep** **Stop**
I²C address **Command**




Advanced



Requesting data from device



Advanced




1 55 46 56 50 0 = 7.82
Dec Dec
ASCII

Response codes

After a command has been issued, a 1 byte response code can be read in order to confirm that the command was processed successfully.

Reading back the response code is completely optional, and is not required for normal operation.



Example

```
I2C_start;  
I2C_address;  
I2C_write(EZO_command);  
I2C_stop;
```

```
delay(300); →  Processing delay
```

```
I2C_start;  
I2C_address;  
Char[ ] = I2C_read;  
I2C_stop;
```


The response code will always be 254, if you do not wait for the processing delay.

Response codes

Single byte, not string


255	no data to send
254	still processing, not ready
2	syntax error
1	successful request

LED color definition




Blue

I²C standby




Green

Taking reading




Purple

Changing I²C address



Red


Command not understood



White

Find

5V	LED ON +0.4 mA
3.3V	+0.2 mA



Solid Green LED

in UART mode
Not I²C ready

I²C mode

command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	
Baud	change back to UART mode	pg. 61
Cal	performs calibration	pg. 47
Export	export calibration	pg. 48
Factory	enable factory reset	pg. 60
Find	finds device with blinking white LED	pg. 45
i	device information	pg. 55
I2C	change I ² C address	pg. 59
Import	import calibration	pg. 49
L	enable/disable LED	pg. 44
Name	set/show name of device	pg. 54
O	removing parameters	pg. 53
P	atmospheric pressure compensation	pg. 52
Plock	enable/disable protocol lock	pg. 58
R	returns a single reading	pg. 46
S	salinity compensation	pg. 51
Sleep	enter sleep mode/low power	pg. 57
Status	retrieve status information	pg. 56
T	temperature compensation	pg. 50

LED control

Command syntax

300ms  processing delay

L,1 LED on **default**

L,0 LED off

L,? LED state on/off?

Example

L,1


Wait 300ms

1
Dec **0**
Null

L,0


Wait 300ms

1
Dec **0**
Null



L,?


Wait 300ms

1 **?L,1** **0**
Dec ASCII Null

or

1 **?L,0** **0**
Dec ASCII Null



L,1

L,0

Find

300ms  processing delay

Command syntax

This command will disable continuous mode
Send any character or command to terminate find.

Find LED rapidly blinks white, used to help find device




Example

Response

Find

 Wait 300ms

1 Dec Null



Taking reading

Command syntax

600ms  processing delay

R return 1 reading

Example

Response


R



1
Dec

7.82
ASCII

0
Null




Green



Taking reading



Wait 600ms



Transmitting



Blue

Standby

Calibration

Command syntax

1300ms  processing delay

Cal	calibrate to atmospheric oxygen levels
Cal,0	calibrate device to 0 dissolved oxygen
Cal,clear	delete calibration data
Cal,?	device calibrated?

The EZO™ Dissolved Oxygen circuit uses single and/or two point calibration

Example

Response

Cal

 Wait 1300ms
1 Dec 0 Null

Cal,0

 Wait 1300ms
1 Dec 0 Null

Cal,clear

 Wait 300ms
1 Dec 0 Null

Cal,?

 Wait 300ms
1 Dec ?Cal,0 0 or 1 Dec ?Cal,1 0
or 1 Dec ?Cal,2 0

Export calibration

300ms  processing delay

Command syntax

Export: Use this command to download calibration settings

Export,? calibration string info

Export export calibration string from calibrated device

Example

Response

Export,?



1 10,120 0
Dec ASCII Null

Response breakdown

10, 120

of strings to export # of bytes to export

Export strings can be up to 12 characters long

Export



1 59 6F 75 20 61 72 0
Dec ASCII Null

(1 of 10)

Export



1 65 20 61 20 63 6F 0
Dec ASCII Null

(2 of 10)

(7 more)

⋮

Export



1 6F 6C 20 67 75 79 0
Dec ASCII Null

(10 of 10)

Export



1 *DONE 0
Dec ASCII Null

Import calibration

300ms  processing delay

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n import calibration string to new device

Example

Import, 59 6F 75 20 61 72 (1 of 10)

Import, 65 20 61 20 63 6F (2 of 10)

⋮

Import, 6F 6C 20 67 75 79 (10 of 10)


Response

 1 0 Null
Wait 300ms


 1 0 Null
Wait 300ms

⋮
 1 0 Null
Wait 300ms

Import,n



system will reboot



* If one of the imported strings is not correctly entered, the device will not accept the import and reboot.

Temperature compensation

Command syntax

Default temperature = 20°C
Temperature is always in Celsius
Temperature is not retained if power is cut

- T,n n = any value; floating point or int 300ms  processing delay
- T,? compensated temperature value?
- RT,n set temperature compensation and take a reading*

This is a new command
for firmware V2.13

Example

T,19.5

Response



 Wait 300ms 1 Dec 0 Null

RT,19.5

 Wait 900ms 1 Dec 8.91 0 Null

T,?

 Wait 300ms 1 Dec ?T,19.5 0 Null



Salinity compensation

Command syntax

300ms  processing delay

- S,n** n = any value in microsiemens default
- S,n,ppt** n = any value in ppt
- S,?** compensated salinity value?

Example

S,50000

Response

 Wait 300ms **1** Dec **0** Null

S,37.5,ppt

 Wait 300ms **1** Dec **0** Null

S,?

 Wait 300ms **1** Dec **?S,50000,µS** ASCII **0** Null
or
1 Dec **?S,37.5,ppt** ASCII **0** Null

If the conductivity of your water is less than 2,500µS this command is irrelevant

Atmospheric pressure compensation

Command syntax

300ms  processing delay

P,n n = any value in kPa

P,? compensated pressure value?

Example


P,90.25

Response

 Wait 300ms
1 Dec 0 Null

P,?

 Wait 300ms
1 Dec ?,P,90.25 0 ASCII Null



Enable/disable parameters from output string

Command syntax

300ms  processing delay

O, [parameter],[1,0]

enable or disable output parameter

O,?

enabled parameter?

Example

Response


O,mg,1 / O,mg,0



1 Dec 0 Null

enable / disable mg/L

O,%,1 / O,%,0



1 Dec 0 Null

enable / disable percent saturation

O,?



1 Dec ? ASCII

0 Null

if both are enabled

Parameters

mg mg/L

% percent saturation

Followed by 1 or 0

1 enabled

0 disabled

* If you disable all possible data types
your readings will display "no output".

Naming device

300ms  processing delay

Command syntax

Do not use spaces in the name

Name,n set name

n =

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Name, clears name

Up to 16 ASCII characters

Name,? show name

Example

Response

Name,



1
Dec
0
Null

name has been cleared

Name,zzt




1
Dec
0
Null

Name,?




1
Dec
?Name,zzt
ASCII
0
Null

Name,zzt



Name,?



1 0

1 ?Name,zzt 0

Device information

Command syntax

300ms  processing delay

i device information

Example Response

i



Wait 300ms

1
Dec

?i,D.O.,1.98
ASCII

0
Null

Response breakdown

?i, D.O., 1.98

↑
Device

↑
Firmware

Reading device status

Command syntax

300ms  processing delay

Status voltage at Vcc pin and reason for last restart

Example Response

Status



Wait 300ms

1

?Status,P,5.038

Dec

ASCII

0

Null

Response breakdown

?Status, P,
Reason for restart 5.038
 Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Sleep mode/low power

Command syntax

Sleep enter sleep mode/low power

Send any character or command to awaken device.

Example

Response

Sleep

no response

Do not read status byte after issuing sleep command.

Any command


wakes up device

5V


	STANDBY	SLEEP
13.1 mA	0.66 mA	

3.3V


12 mA	0.3 mA
--------------	---------------



Standby



Sleep



Sleep

Protocol lock

Command syntax

300ms  processing delay

Plock,1 enable Plock

Locks device to I²C mode.

Plock,0 disable Plock

default

Plock,? Plock on/off?

Example

Plock,1

 Wait 300ms

1
Dec
0
Null

Plock,0


 Wait 300ms

1
Dec
0
Null


Plock,?

 Wait 300ms


1
Dec
?Plock,1
ASCII
0
Null



Baud, 9600



cannot change to UART



cannot change to UART

I²C address change

Command syntax

300ms  processing delay

I²C,n sets I²C address and reboots into I²C mode

Example Response

I²C,100

device reboot

(no response given)



Warning!

Changing the I²C address will prevent communication between the circuit and the CPU until your CPU is updated with the new I²C address.


Default I²C address is 97 (0x61).

n = any number 1 – 127

I²C,100



(reboot)



Factory reset

Command syntax

Factory reset will not take the device out of I²C mode.

Factory enable factory reset

I²C address will not change

Example Response


Factory

device reboot


(no response given)

Clears calibration
LED on
Response codes enabled

Factory



(reboot)



Change to UART mode

Command syntax

Baud,n switch from I²C to UART


Example Response

Baud,9600



reboot in UART mode

(no response given)


n = [300
1200
2400
9600
19200
38400
57600
115200]



Baud,9600



(reboot)




Changing to
UART mode


Manual switching to UART

- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to PGND
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Blue to Green
- Disconnect ground (power off)
- Reconnect all data and power

Example



Wrong Example



Calibration theory

The accuracy of your readings is directly related to the quality of your calibration.
(Calibration is not difficult, and a little bit of care goes a long way).

Confirm the D.O. probe is working correctly

Take readings in air first.



Readings > 10



Readings < 5 or > 25

*Refer to probes datasheet
for instructions.*

Calibrate first, compensate later

Compensating for temperature, pressure, and salinity will change your calibrated readings to a value that cannot easily be predicted. This makes it difficult to know if the probe has been calibrated correctly.

Default compensation values

Temp = 20 °C

Pressure = 101 kPa

Salinity = 0

Known calibration value

9.09 Mg/L

Temp = 29 °C

Pressure = 93 kPa

Salinity = 5


(too many variables)

???

(6.84 Mg/L)

Best practices for calibration

Always watch the readings throughout the calibration process.
Issue calibration commands once the readings have stabilized.



⚠ Never do a blind calibration! ⚠




Issuing a calibration command before the readings stabilize will result in drifting readings.



Calibration order

High point calibration

Remove the Dissolved Oxygen probe's cap and let the probe sit, exposed to air until the readings stabilize. (small movement from one reading to the next is normal).





After calibration is complete, you should see readings between **9.09 – 9.1X mg/L**.
(only if temperature, salinity and pressure compensation are at default values)



Low point calibration

After you have calibrated the EZO™ Dissolved Oxygen circuit using the "Cal" command; Remove the top of the Zero Dissolved Oxygen calibration solution pouch, and Insert the probe and stir it around to remove any trapped air (which could cause readings to go high). Let the probe sit in Zero D.O. calibration solution until readings stabilize.
(small movement from one reading to the next is normal).



Advanced calibration

Probe temperature calibration

Probe temperature calibration ≠ Temperature compensation.

When a Dissolved Oxygen probe is calibrated, it is calibrated to the oxygen level and ambient temperature. As a D.O. probe is heated or cooled, its response curve will change. A small temperature change ($\leq 5^{\circ}\text{C}$) will not affect the probe. However, a large temperature change will be noticeable.




Calibrated probe

Air temperature

23°C

Air Reading


9.10 mg/L



Advanced calibration

What to do:

After the Dissolved Oxygen probe has been properly calibrated, another calibration can be done to account for the probe temperature.




Let the probe acclimate to its operating temperature and then recalibrate. Once the probe has been calibrated at its intended operating temperature, using temperature compensation will give accurate readings.

Understanding D.O. measurements

Most chemical sensors do not directly measure the parameter they are designed for. Dissolved oxygen is no exception. A galvanic D.O. probe is actually an oxygen pressure sensor. It only measures the partial pressure of oxygen.

Keep this in mind when choosing a spot to place the probe.



It just so happens that partial pressure of oxygen is the same in water as it is in air.

(While the pressure is the same, the amount is not. Pure water at sea level can only hold ~9 mg/L of oxygen, while the atmosphere holds ~300mg/L)

By comparing oxygens pressure to its solubility in water, the mg/L are derived.

There are three factors that affect waters ability to hold oxygen.

Temperature

Salinity

Atmospheric Pressure

Temperature

Water temperature has the largest effect; the colder the water, the more oxygen it holds. As water heats up, its ability to hold oxygen goes down.

Pure water at 1°C can hold 14.2 mg/L

And at 40°C it can only hold 6.4 mg/L


Understanding D.O. measurements

Salinity

When salt is added to water, it drives out oxygen by competing for the same space.

Sea water at 1°C can only hold 10.7 mg/L

Pure water at 1°C can hold 14.2 mg/L



Atmospheric Pressure

A D.O. probe is an oxygen pressure sensor.

Dissolved oxygen pressure cannot be higher than atmospheric oxygen pressure. This is why the probe is calibrated to the atmosphere; it defines the probe's response to the maximum oxygen pressure available. However, oxygen pressure does not tell us how much oxygen is available to dissolve in the water. That information is derived from atmospheric pressure (where atmospheric pressure = altitude).


As altitude increases, oxygen concentration decreases, and because D.O. readings are expressed in Mg/L, the oxygen concentration must be known.

At sea level, 1°C pure water can hold 14.2 mg/L

At 1,500 meters, 1°C pure water can hold 11.7 mg/L

At -1,200 meters, 1°C pure water can hold 16.2 mg/L

Flow Dependence




One of the drawbacks from using a galvanic probe is that it consumes a **VERY** small amount of the oxygen it reads. Therefore, a small amount of water movement is necessary to take accurate readings. **Approximately 60 ml/min.**

Hyper saturation with pure oxygen

Dissolved oxygen measurements are based on natural occurring oxygen levels. However, some applications may require pure oxygen to achieve extremely high saturation levels. Because injecting pure oxygen into water is not a naturally occurring event, you will need to change some compensation parameters to achieve extremely high readings.

To reach 100mg/L and a saturation of 350%


Set pressure compensation to: **202 kPa**
Set temperature compensation to: **1°C**



Soldering


Do not directly solder an EZO circuit to your PCB. If something goes wrong during the soldering process it may become impossible to correct the problem. It is simply not worth the risk.

Instead, solder female header pins to your PCB and place the EZO device in the female headers.



**Avoid using rosin core solder.
Use as little flux as possible.**

Flux residue will severely affect your readings. Any Flux residue that comes in contact with the PRB pins or your probes connector will cause a "flux short".




You **MUST** remove all the flux residue from your PCB after soldering.

Soldering

Removing flux residue can be done with commercially available products such as flux off or you can use alcohol and a tooth brush.



Remove EZO Circuit and soak in alcohol for 10 mins.




Bush with tooth brush.



Soak in alcohol for 5 mins.






Let it dry in the air.




What does a flux short look like?

Readings move slowly and take serval minutes to reach the correct value.


EZO™ circuit footprint




1 In your CAD software place a 8 position header.



2 Place a 3 position header at both top and bottom of the 8 position.



3 Delete the 8 position header. The two 3 position headers are now 17.78mm (0.7") apart from each other.



Datasheet change log

Datasheet V 5.6

Revised entire document.

Datasheet V 5.5

Revised naming device info on pages 32 & 59.

Datasheet V 5.4

Revised artwork within datasheet.

Datasheet V 5.3

Moved Default state to pg 13.

Datasheet V 5.2

Updated firmware changes on page 70.

Datasheet V 5.1

Revised response for the sleep command in UART mode on pg 36.

Datasheet V 5.0

Revised calibration theory on page 9, and added more information on the Export calibration and Import calibration commands.

Datasheet V 4.9

Corrected temperature compensation typo on pages 26 & 52.

Datasheet V 4.8

Revised isolation schematic on pg. 10

Datasheet V 4.7

Added new command:

"RT,n" for Temperature compensation located on pages 26 (UART) & 52 (I²C).
Added firmware information to Firmware update list.

Datasheet change log

Datasheet V 4.6

Added more information about temperature compensation on pages 26 & 52.

Datasheet V 4.5

Changed "Max rate" to "Response time" on cover page.

Datasheet V 4.4

Removed note from certain commands about firmware version.

Datasheet V 4.3

Added information to calibration theory on pg 7.

Datasheet V 4.2

Revised definition of response codes on pg 44.

Datasheet V 4.1

Updated firmware changes on pg. 66.

Datasheet V 4.0

Revised Enable/disable parameters information on pages 29 (UART) & 55 (I²C).

Datasheet V 3.9

Revised information on cover page.

Datasheet V 3.8

Update firmware changes on pg. 66.

Datasheet V 3.7

Revised Plock pages to show default value.

Datasheet change log

Datasheet V 3.6

Added new commands:

"Find" pages 21 (UART) & 48 (I²C).
"Export/Import calibration" pages 25 (UART) & 51 (I²C).
Added new feature to continuous mode "C,n" pg 22.

Datasheet V 3.5

Added accuracy range on cover page, and revised isolation info on pg. 10.

Datasheet V 3.4

Added manual switching to UART information on pg. 59.

Datasheet V 3.3

Updated firmware changes to reflect V1.99 update.

Datasheet V 3.2

Revised entire datasheet.

Firmware updates

V1.1 – Initial release (Oct 30, 2014)

- Change output to mg/L, then percentage (was previously percentage, then mg/L).

V1.5 – Baud rate change (Nov 6, 2014)

- Change default baud rate to 9600

V1.6 – I²C bug (Dec 1, 2014)

- Fixed I²C bug where the circuit may inappropriately respond when other I²C devices are connected.

V1.7 – Factory (April 14, 2015)

- Changed "X" command to "Factory"

V1.95 – Plock (March 31, 2016)

- Added protocol lock feature "Plock"

V1.96 – EEPROM (April 26, 2016)

- Fixed bug where EEPROM would get erased if the circuit lost power 900ms into startup.

V1.97 – EEPROM (Oct 10, 2016)

- Fixed bug in the cal clear command, improves how it calculates the DO, adds calibration saving and loading.

V1.98 – EEPROM (Nov 14, 2016)

- Updated firmware for new circuit design.

V1.99 – (Feb 2, 2017)

- Revised "O" command to accept mg.

V2.10 – (April 12, 2017)

- Added "Find" command.
- Added "Export/import" command.
- Modified continuous mode to be able to send readings every "n" seconds.

V2.11 – (Sept 28, 2017)

- Fixed bug where the temperature would default to 0 on startup.

V2.12 – (Dec 19, 2017)

- Improved accuracy of dissolved oxygen equations.

V2.13 – (July 16, 2018)

- Added "RT" command to Temperature compensation.

V2.14 – (June 7, 2019)

- Fixed bug where the output buffer overflows when the cal and cal,0 point are too close together.

Firmware updates

V2.15 – (Sept 8, 2022)

- Internal update for new part compatibility.

Warranty

Atlas Scientific™ Warranties the EZO™ class Dissolved Oxygen circuit to be free of defect during the debugging phase of device implementation, or 30 days after receiving the EZO™ class Dissolved Oxygen circuit (which ever comes first).

The debugging phase

The debugging phase as defined by Atlas Scientific™ is the time period when the EZO™ class Dissolved Oxygen circuit is inserted into a bread board, or shield. If the EZO™ class Dissolved Oxygen circuit is being debugged in a bread board, the bread board must be devoid of other components. If the EZO™ class Dissolved Oxygen circuit is being connected to a microcontroller, the microcontroller must be running code that has been designed to drive the EZO™ class Dissolved Oxygen circuit exclusively and output the EZO™ class Dissolved Oxygen circuit data as a serial string.

It is important for the embedded systems engineer to keep in mind that the following activities will void the EZO™ class Dissolved Oxygen circuit warranty:

- **Soldering any part of the EZO™ class Dissolved Oxygen circuit.**
- **Running any code, that does not exclusively drive the EZO™ class Dissolved Oxygen circuit and output its data in a serial string.**
- **Embedding the EZO™ class Dissolved Oxygen circuit into a custom made device.**
- **Removing any potting compound.**

Reasoning behind this warranty

Because Atlas Scientific™ does not sell consumer electronics; once the device has been embedded into a custom made system, Atlas Scientific™ cannot possibly warranty the EZO™ class Dissolved Oxygen circuit, against the thousands of possible variables that may cause the EZO™ class Dissolved Oxygen circuit to no longer function properly.

Please keep this in mind:

- 1. All Atlas Scientific™ devices have been designed to be embedded into a custom made system by you, the embedded systems engineer.**
- 2. All Atlas Scientific™ devices have been designed to run indefinitely without failure in the field.**
- 3. All Atlas Scientific™ devices can be soldered into place, however you do so at your own risk.**

Atlas Scientific™ is simply stating that once the device is being used in your application, Atlas Scientific™ can no longer take responsibility for the EZO™ class Dissolved Oxygen circuits continued operation. This is because that would be equivalent to Atlas Scientific™ taking responsibility over the correct operation of your entire device.